

WISCONSIN

Air Cooled

HEAVY DUTY ENGINES

INSTRUCTION BOOK AND PARTS LIST

Models

TE

TF

ISSUE WW249-C

WORLD'S LARGEST BUILDERS OF HEAVY DUTY AIR COOLED ENGINES

IMPORTANT

STARTING AND OPERATING OF NEW ENGINES

Careful breaking in of a new engine will greatly increase its life and result in trouble-free operation. A factory test is not sufficient to establish the polished bearing surfaces, which are so necessary to the proper performance and long life of an engine. Neither is there a quick way to force the establishment of good bearing surfaces. These can only be obtained by running a new engine carefully and under reduced speeds and loads for a short time, as follows:

First, be sure the engine is filled to the proper level with a good quality of engine oil, see "Grade of Oil" chart.

Before a new engine is put to its regular work, the engine should be operated at low idle speed (1000 to 1200 R.P.M.) for one half hour, without load. The R.P.M. should then be increased to engine operating speed, still without load, for an additional two hours.

If at all possible, operate the engine at light loads for a period totaling about eight hours, before maximum load is applied. This will greatly increase engine life.

The various bearing surfaces in a new engine have not been glazed, as they will be with continued operation, and it is in this period of "running in," that special care must be exercised, otherwise the highly desired glaze will never be obtained. A new bearing surface that has once been damaged by carelessness will be ruined forever.

READ INSTRUCTIONS CAREFULLY

A copy of this manual is sent out with each engine. All points of operation and maintenance have been covered as carefully as possible but if further information is required, inquiries sent to the factory will receive prompt attention.

When writing the factory ALWAYS GIVE THE MODEL AND SERIAL NUMBER of engine referred to.

Manual Price \$1.50

WISCONSIN MOTOR CORPORATION
MILWAUKEE, WISCONSIN 53246



BOOK OF INSTRUCTIONS

WISCONSIN *Air-Cooled*

TWO CYLINDER ENGINES



READ THE *STARTING AND OPERATING INSTRUCTIONS* THOROUGHLY BEFORE STARTING A NEW ENGINE. BECOME ACQUAINTED WITH THE ENGINE COMPONENTS; THEIR LOCATION, MAINTENANCE AND ADJUSTMENT REQUIREMENTS.

MODEL TE

3" Bore
3 $\frac{1}{4}$ " Stroke
45.9 cu. in. Disp.

MODEL TF

3 $\frac{1}{4}$ " Bore
3 $\frac{1}{4}$ " Stroke
53.9 cu. in. Disp.

Models **TE**
TF


ISSUE MM# 249-C

NOTE: Engines having Stellite Exhaust Valves and Inserts are designated as Models TED and TFD.

INDEX

	PAGE		PAGE
Air Cleaner	8	Illustration of Engines	3-4
Backfires Through Carburetor	17	Knocks - Engine	17
Battery Ignition Distributor	11	Lubrication	7
Battery Ignition - Wiring and Timing Diagram ...	13	Lubrication System - Diagram	6
Carburetor Adjustment	10	Magneto Breaker Point Adjustment	10
Carburetor Repair - See Manufacturer's bulletin in back of Manual.		Magneto Ignition Spark	10
Choke	10	Magneto Repair - See Manufacturer's bulletin in back of Manual.	
Clutch	24	Magneto Timing Diagram	12
Clutch Adjustment	24	Magneto Timing	10
Compression	16	Oil - Grade of	8
Compression - Restoring	15	Oil Pump - Engine Base and	20
Cooling	7	Oil Spray Nozzles	23
Crankshaft - End Play	22	Overheating	17
Cross Section of Engine	5	Parts List	27
Cylinders - Oversize (See Cylinder Block)	21	Piston - Rings - Rod Clearances	21
Disassembling and Reassembling	17	Reduction Gears	25
Distributor - Battery Ignition	11	Safety Precautions	15
Electric Starter and Generator	14	Service Station Directory, See back of Manual.	
Engine Models	1	Spark Plugs	14
Firing Order	14	Starting and Operating Instructions	8
Fuel	9	Starting - Crank	15
Fuel Pump	9	Starting Difficulties	16
Gasoline Strainer	9	Stop Engine - Vapor Lock and Dieseling	15
Gears - Timing (Fig. 22)	20	Storage of Engine for Winter	25
General Information and Design	7	Surging or Galloping	17
Horse Power	7	Troubles - Causes and Remedies	16
Governor	7	Valves - Grinding and Tolerances	22
Ignition Switch	10	Valve Tappets	23
Ignition Troubles	16	Warm-Up Period, Overspeeding	15


PAGE
3-4
17
7
6
10
10
12
10
8
20
23
17
27
21
25
15
14
8
15
16
15
25
17
16
22
23
15



189168C

Fig. 1

TAKE-OFF (Side Mount Tank) VIEW OF ENGINE




148496C

Fig. 2

POWER UNIT FAN END VIEW OF ENGINE

TANK
R
ABER



148496C

Fig. 3
CROSS SECTION OF ENGINE

NOTE:
 CYLINDERS, RINGS, PISTONS, PINS,
 TAPPETS, VALVES, CAMSHAFT, BEARINGS
 AND ETC. ARE LUBRICATED BY THE OIL
 SPRAY OR MIST THROWN OFF THE
 CONNECTING RODS AND CRANKSHAFT.

RESTRICTED FITTING
 GOVERNOR ASSEMBLY
 (ON RIGHT HAND
 SIDE OF ENGINE)

OIL LINE TO GOVERNOR




Fig. 4

LUBRICATION SYSTEM

GENERAL INFORMATION

Wisconsin heavy duty air cooled engines are of the most approved design, built in a modern factory, equipped with the latest machinery available. Only the best materials, most suitable for the particular part, are used. During production every part is subjected to the most rigid inspection, as are also the completely assembled engines. After assembly every engine is operated on its own power, for several hours, on a dynamometer. All adjustments are carefully made so that each engine will be in perfect operating condition when it leaves the factory.

Back of the Wisconsin Motor Corporation is fifty years of engineering experience in the design of gasoline engines for every conceivable type of service. The performance of these engines is proof of the long satisfactory service you too can expect from your engine.

Like all fine machinery an engine must be given regular care and operated in accordance with instructions.

Keep this book handy at all times, familiarize yourself with the operating instructions.

GENERAL DESIGN

Wisconsin engines are of the four cycle type, in which each of the four operations of suction, compression, expansion and exhaust requires a complete stroke. This gives one power stroke per cylinder for each two revolutions of the crankshaft.

COOLING

Cooling is accomplished by a flow of air, circulated over the cylinders and heads of the engine, by a combination fan-flywheel encased in a sheet metal shroud. The air is divided and directed by ducts and baffle plates to insure uniform cooling of all parts.

Never operate an engine with any part of the shrouding removed, because this will retard the air cooling.

CARBURETOR

The proper combustible mixture of gasoline and air is furnished by a balanced carburetor, giving correct fuel to air ratios for all speeds and loads.

IGNITION

The spark for ignition of the fuel mixture is furnished by a high tension magneto driven off the timing gears at crankshaft speed. The magneto is fitted with an impulse coupling, which makes possible a powerful spark for easy starting. Also, the impulse coupling automatically retards the timing of the spark for starting, thus eliminating danger of a kick back from the engine when starting. When electric starter and generator are furnished, battery ignition is used. See Page 11.

LUBRICATION

A plunger type pump supplies oil to a spray nozzle which directs oil streams against holes in the connecting rods, and to an oil header line, connected to the governor housing, which lubricates the timing gear train. Part of the oil from the oil spray nozzle enters the rod bearings thru holes in the rods and the balance of the oil forms a spray or mist which lubricates the cylinders and all other internal parts of the engine. See Fig. 4.

GOVERNOR

A governor of the centrifugal flyball type controls the engine speed by varying the throttle opening to suit the load imposed upon the engine.

ROTATION

The rotation of the crankshaft is clockwise when viewing the flywheel or starting end of the engine. This gives counter-clockwise rotation when viewing the power take-off end of the crankshaft.

HORSE POWER

R.P.M.	TE	TF
1400	7.2	8.7
1600	8.3	10.1
1800	9.3	11.4
2000	10.0	12.4
2200	10.6	13.2
2400	10.9	14.0
2600	11.2	14.6

HORSE POWER

The horse power given in the above chart is for an atmospheric temperature of 60° Fahrenheit, at sea level, and at a Barometric pressure of 29.92 inches of mercury.

For each inch lower Barometer reading deduct 3½% from above horsepower.

For each 10° higher temperature there will be a reduction in horsepower of 1%.

For each 1000 ft. altitude above sea level there will be a reduction in horsepower of 3½%.

The friction in new engines cannot be reduced to the ultimate minimum during the regular block test, but engines are guaranteed to develop at least 85 per cent of maximum power when shipped from the factory. The power will increase, as friction is reduced, during a few days of operation. The engine will develop at least 95% of power shown on chart when friction is reduced to a minimum.

For continuous operation allow 20% of horse power shown, as a safety factor.

INSTRUCTIONS FOR STARTING AND OPERATING

Some of these engines are furnished with a house, as shown in Fig. 2, and are called power units. Others are furnished without a house, as shown in Fig. 1, and are called open engines.

On engines with a house the side doors should always be removed when operating.

This is to give better circulation of air for cooling the engine.

LUBRICATION

Before starting the engine, fill the oil base with good gasoline engine oil *up to FULL line on oil gauge* *sabre, see Fig. 4.* The combination oil gauge sabre and filler is on the magneto side of the standard engine.

On engines with generator and distributor ignition, the oil level gauge plug is a separate unit mounted directly beneath the distributor. The oil filler cap is mounted along side of the generator.

Too much emphasis cannot be given to the matter of oil selection. High grade oil of the body suited to the requirements of your engine is the most important single item in the economical operation of the unit, yet it is the cheapest item of operating cost. Select your oil solely on quality and suitability—never on price—for no one thing is so sure to bring about unsatisfactory performance and unnecessary expense as incorrect lubrication.

High-grade, highly refined oils corresponding in body to the S.A.E. (Society of Automotive Engineers) Viscosity Numbers listed in the following chart will prove economical and assure long engine life.

GRADE OF OIL

SEASON OR TEMPERATURE	GRADE OF OIL	EXAMPLE
Spring, Summer or Autumn +120°F to +40°F	SAE 30	Mobiloil A
Winter +40°F to +5°F	SAE 20-20W	Mobiloil Arctic
Winter +5°F to -20°F	SAE 10W	Mobiloil 10W
Crankcase Capacity		3½ Qts.

Important: S.A.E. Viscosity Numbers classify oils in terms of body only, without consideration of quality or character, therefore we list certain grades of *Mobil oil* as typical examples of lubricants possessing the qualities we believe desirable in oils for *Wisconsin* engines. We plainly state that these grades of *Mobil-oils* are listed because of their recognized quality and world-wide distribution. *There are other high quality oils on the market that are equally satisfactory for Wisconsin engines.*

GRADE OF OIL

Follow summer recommendations in winter if engine is housed in warm building.

Check oil level every 8 hours of operation.

The old oil should be drained and fresh oil added after every 50 hours of operation.

To drain oil remove drain plug. *See Fig. 4.* Oil should be drained while engine is hot, as it will then flow more freely.

AIR CLEANER

The air cleaner is an essential accessory, filtering the air entering the carburetor, and thereby prolonging the life of the engine.



Fig. 5

148487C-1

Remove the cover and filtering element from the air cleaner. *See Fig. 5.* Fill bowl to oil level line with the same grade of oil as used in the crankcase. The filtering element should be washed in solvent if it shows signs of collected dust. Detailed instructions are printed on the Air Cleaner.

The air cleaners must be serviced frequently, depending on the dust conditions where the engines are operated. When the oil in the bowl becomes dirty it should be removed and replaced with new oil. This servicing will vary from a few days of operation in comparatively clean conditions to twice a day in dusty conditions.

Operating the engine under dusty conditions without oil in the air cleaner or with dirty oil, may wear out cylinders, pistons, rings and bearings in a few days time, and result in costly repairs.

Daily attention to the air cleaner is one of the most important considerations in prolonging engine life.

The gear cover breather is mounted underneath the air cleaner bracket. See Fig. 5 which shows the breather removed. This breather should be removed periodically and thoroughly cleaned to be sure that the check ball is free. If the breather becomes dirty so that the check ball is not free to function properly, a pressure will be built up in the gear cover causing oil leakage at seal and poor oil economy.

FUEL

These engines are furnished either with gravity feed tanks mounted above the level of the carburetor, or with side mount tanks, or tanks mounted below the engine. In the latter two cases, fuel pumps are furnished on the engines, to pump the fuel up to the carburetor.

The fuel tank should be filled with a good quality of gasoline free from dirt and water. Some of the poorer grades of gasoline contain gum which will deposit on valve stems, piston rings, and in various small passages in the carburetor and thus cause serious trouble in operating, and this might prevent the engine from operating at all.

Use only reputable, well known brands of **Regular** gasoline. Fuels with the lowest possible lead content, but not below octane rating 74 (Research Method), are best. Fuel with a lower octane rating will cause detonation, and if operation is continued under this condition, severe damage will result to the engine. The cylinders and pistons will be scored, head gaskets blown out, bearings will be damaged, etc.

Be sure to open the shut off valve in the gasoline strainer before starting. Also, be sure air vent hole in fuel tank cap is open, otherwise gas cannot flow to carburetor.

GASOLINE STRAINER

The gasoline strainer is very necessary to prevent sediment, dirt and water from entering the carburetor and causing trouble or even complete stoppage of the engine. This strainer has a glass bowl and should be inspected frequently, and cleaned if dirt or water are present. To remove bowl, first shut off fuel valve, then loosen the knurled nut below bowl and swing the wire bail to one side. After cleaning bowl and screen replace the parts, being sure the gasket is in good condition; otherwise use a new gasket. See Fig. 6 which shows the gasoline strainer mounted to the fuel tank of a power unit. On open engines the strainer is mounted to the inlet of the fuel pump.

FUEL PUMP

On engines equipped with fuel pumps, when starting




Fig. 6

71051C

the first time, or when engines have been out of operation for a while, the hand primer lever on the fuel pump should be used before attempting to start, so that fuel may be pumped into the dry carburetor, otherwise starting would be very difficult. When priming by hand lever, a distinct resistance of the fuel pump diaphragm should be felt. If this is not the case the engine should be turned over a revolution so that the fuel pump cam will be rotated from its upper position which would prevent hand priming.




Fig. 7

189166C

Assuming the gasoline strainer is empty, approximately 25 strokes of the primer lever are required to fill the bowl. See Fig. 7. After strainer bowl is full, an additional 5 to 10 strokes are required to fill the carburetor bowl. When the carburetor is full the hand primer lever will move more easily. Instructions for fuel pump maintenance and repair are located in the back of this manual.

CHOKE

Before starting a cold engine close the choke on the carburetor by pulling out the choke button at the flywheel end of the engine. See Fig. 1 and 2. When the engine is started the choke should be opened gradually as the engine warms up. More choking is necessary when starting in cold weather than in warm. If the engine is warm, very little choking is necessary. The operator will soon gain experience in how much choking is necessary. The choke button should always be pushed in after the engine is warmed up.

The choke is closed when button is pulled out, and open when button is pushed in.

CARBURETOR ADJUSTMENT

The main metering jet in the carburetor is of the fixed type, that is, it requires no adjustment. The idle needle should be adjusted for best low speed operation, while carburetor throttle is closed by hand. For illustrations and more information see Carburetor Manufacturer's Instruction Bulletin in back of this manual.

IGNITION SWITCH

Magneto ignition is standard on these engines, with a lever type switch, on the side of the magneto, which is always in the *on* or running position, except when depressed for stopping the engine. See Fig. 1.

On engines with a house, the ignition switch is on the outside of the house at the flywheel end. See Fig. 2. To run engine with magneto ignition, this switch is pushed in; with battery ignition, it is pulled out.

MAGNETO BREAKER POINT ADJUSTMENT

Magnetos are properly adjusted before leaving factory. The breaker point gap on the Fairbanks-Morse magneto and the Wico magneto should be .015" at full separation. If the spark becomes weak after continued operation it may be necessary to readjust these points. To do this first remove the end cover on the magneto. See Fig. 8 and Fig. 9 which show the end




Fig. 8

189167C




Fig. 9

cover of the Fairbanks-Morse magneto removed. The crankshaft should then be rotated with the starting crank, (this also rotates the magneto), until the breaker points are wide open. The opening or gap should then be measured with a feeler gauge and if necessary reset as shown in Fig. 9. To readjust points first loosen the lock-screw on the breaker point plate, then insert the end of a small screwdriver into the adjusting slot and open or close breaker points until proper gap is attained, then be sure to retighten lock-screw. All of these parts are shown in Fig. 9. After tightening lock-screw, recheck breaker point gap, to make sure it has not changed. If it is found that the breaker points have become rough, they should be smoothed with a breaker point file before the above adjustments are made. Then replace magneto end cover carefully so that it will seal properly. Do not force cover screws too tightly otherwise cover may crack. For further information see Fairbanks-Morse or Wico Magneto Maintenance Instructions in back of this manual.

MAGNETO IGNITION SPARK

If difficulty is experienced in starting the engine or if engine misses firing, the strength of the ignition spark may be tested by removing the ignition cable from No. 1 spark plug and holding the terminal 1/8 inch away from the cylinder head shroud, as shown in Fig. 10. Turn the engine over slowly by the starting crank as shown.

When the impulse coupling on the magneto snaps there should be a good spark at the ignition cable terminal. If there is a weak spark, or none at all, first check breaker point opening as mentioned in preceding paragraph under 'Magneto'. If this does not remedy the trouble, it may be necessary to install a new condenser. See Magneto Manufacturer's Maintenance Instructions in back of this manual.

MAGNETO TIMING

The magneto is properly timed at the factory, but if





Fig. 10

148498C

for any reason it is necessary to retime the magneto, the following instructions will be helpful.

First remove the screen over the flywheel air intake opening by taking out the screws holding the screen in place. This will expose the timing marks on flywheel shroud for timing magneto. See Timing Diagram, Fig. 11.

Next, remove the spark plug that is closest to the flywheel end of the engine. This is the No. 1 cylinder spark plug. Then, hold the thumb over the spark plug hole and turn the engine over slowly with the starting crank until a definite pressure can be felt, tending to push the thumb away from the spark plug hole. When this occurs, the No. 1 piston is coming up on compression stroke.

The flywheel is marked with the letters 'DC' near one of the air circulating vanes. This vane is further identified by an 'X' mark, cast on the end. See Magneto Timing Diagram, Fig. 11. With the No. 1 piston coming up on the compression stroke, continue turning the starting crank until the edge of the 'X' marked vane on the flywheel is in line with the vertical centerline mark on the shroud as shown on Timing Diagram, Fig. 11. Then leave flywheel in this position, as the No. 1 piston is now on top dead center.

Next, remove the inspection hole plug from the magneto timing opening in the engine gear cover as shown in Fig. 11.

Assuming that the magneto has been removed from the engine, the following procedure should be followed before replacing magneto:

Turn the magneto gear in a clockwise rotation until the impulse snaps. Then, hold the gear in this position and mount the magneto to the engine, meshing the gears so that the 'X' marked tooth on the magneto gear is centrally located in the inspection hole of the gear cover as shown on magneto Timing Diagram, Fig. 11. Tighten the two magneto mounting screws and be sure the magneto flange gasket is in place.

The split-coil magneto furnished on these engines, has no distributor or internal timing gears, and provides two sparks simultaneously (one for each terminal) every 360° of rotation. One spark is used for ignition, the other is wasted in the exhaust. Therefore, either tower can be used to connect the ignition wires to the spark plugs, but for convenience in assembly the tower on the magneto nearest the engine is used as the No. 1 spark plug tower.

Early model engines had a distributor type magneto in which alternate firing of the spark plugs occurred and each plug fired every 720° of rotation. Thus the firing of No. 1 spark plug terminal had to be determined before mounting magneto to engine.

The proper spark advance is 27° . For checking timing with a neon light, the advance mark is located on the flywheel shroud, 27° or about $2\frac{1}{2}''$ to the left of the vertical centerline, as shown on Fig. 11. With the engine operating at normal speed, the ignition spark takes place when the 'X' marked vane on the flywheel lines up with the running spark advance mark on the shroud.

The magneto rotates at crankshaft speed in a clockwise direction when viewing driving gear end of magneto.

BATTERY IGNITION DISTRIBUTOR

When these engines are furnished with electric starters and generators, battery ignition is used, instead of magneto ignition. The ignition timer and distributor are mounted on the end of the generator.

The distributor is of the automatic advance type and it is driven off an engine speed shaft through a pair of two to one ratio helical gears, thus giving the distributor one half engine speed in a counter-clockwise direction when viewed from above.

The proper spark advance for normal speeds is 27° , the same as for magneto ignition.

The distributor is of course properly timed at the factory, but the following instructions are given as a help in retiming if this becomes necessary for any reason.

First remove the screen over the flywheel air intake opening by taking out the screws holding the screen in place. This will expose the timing marks on the flywheel shroud, also the vane on flywheel, marked by an 'X' and the letters DC. See Fig. 12. Then re-




Fig. 11

MAGNETO TIMING DIAGRAM




Fig. 12

BATTERY IGNITION - WIRING AND TIMING DIAGRAM




Fig. 13

148493C

move the spark plug from No. 1 cylinder and turn engine over slowly, by the starting crank until the compression blows the air out of the spark plug hole.

Continue turning starting crank until the leading edge of the 'X' marked vane on flywheel is in line with the vertical center line mark on the flywheel shroud. See Fig. 12. The No. 1 piston is now on top dead center.

Remove distributor cap by disengaging snap hooks.

The distributor should be assembled to the generator with the rotor lined up with center of the notch in the distributor housing. See Fig. 13.

The spark advance lever should now be locked firmly in position by the advance lever lock screw, as a manual spark advance is not used with these engines.

With the distributor clamp screw loose, see Fig. 13, first turn the distributor body slightly in a counter-clockwise direction until the breaker points are firmly closed. Then turn the distributor body in a clockwise direction until the breaker points are just beginning to open. At this point a slight resistance can be felt as the breaker point cam strikes the breaker point arm. The distributor clamp screw should then be tightened, so the distributor will be held firmly in this position. The breaker point gap should be .018 to .022 inches. This opening should be checked before the distributor body is set, otherwise any adjustment made to the breaker point opening will change the ignition advance adjustment. If care is exercised in the above operations the spark timing should be accurate enough for satisfactory operation, however checking spark advance with a neon lamp, as described below, is recommended.

NEON LAMP TIMING

Connect the neon lamp in series with No. 1 spark plug. Chalk or paint the end of the 'X' marked vane on the flywheel, white. Then with the engine operating at 1800 R.P.M. or over, allow the flash from the neon lamp to illuminate the whitened vane. At the time of the flash, the leading edge of the vane should line up with the running spark advance timing mark on the flywheel shroud. See Fig. 12. If it does not,

the distributor clamp screw should be loosened as shown in Fig. 13, and the distributor body turned slightly clockwise or counter-clockwise, as required, until the advance timing mark and the white vane coincide. Be sure the distributor clamp screw is then carefully tightened. If the engine is running below 1800 R.P.M. when timing, the automatic advance in the distributor will not be fully advanced and the timing would not be accurate.

The inner tower in the distributor cap which is in line with the notch in the distributor body is for No. 1 spark plug cable. The center tower from the distributor is connected to the ignition coil and the outer tower is for No. 2 spark plug cable.

The grease cup on the distributor and generator should be given one turn every 50 hours of operation. Use a high melting point grease. Do not over lubricate, otherwise grease will enter the generator and the distributor and may cause trouble.

FIRING ORDER

The cylinders in these engines fire 360 degrees or one crankshaft revolution apart. In other words the power strokes are evenly divided, thus giving a minimum of fluctuation in rotative speed. This is especially valuable in electric generator drives, as with these engines no flicker in lights is noticeable.




Fig. 14

104713C

SPARK PLUG

The spark plug gap should be thirty thousandths (.030) of an inch, and plugs should be kept clean both inside and out. See Fig. 14. If the porcelain insulator is cracked, replace with a new plug of correct heat range, like Champion No. D-16, AC No. C86 Commercial, or equal. The spark plug thread is 18 millimeter. Be sure to use a good gasket under the spark plug. Tighten spark plugs, 24 to 26 foot pounds torque.

ELECTRIC STARTER AND GENERATOR

The electric starter is an optional accessory, furnished only upon request when engine is purchased. The starter and generator cannot be mounted in the field unless provisions were made when engine was purchased. The starter and generator are products of the Electric Auto-Lite Company, Toledo, Ohio, and it is recommended that all repairs for this accessory be done through their authorized Service Stations. For wiring diagram, see Fig. 12. Battery is not furnished by engine manufacturer.

SUPPLEMENT

HIGH TEMPERATURE SAFETY SWITCH

As a safety precaution, some engines have a high temperature safety switch mounted on the cylinder head near the No. 2 spark plug, which will automatically stop the engine when head temperatures rise beyond a safe degree.

This switch is set by the manufacturer to operate at the correct temperature. Consequently, the adjusting screw on the top of the switch should not be tampered with. If the cylinder head temperature at the spark plug reaches 550°F., the switch will automatically short out the magneto, or distributor, and stop the engine. A waiting period of 3 to 5 minutes will be required before the switch has cooled off sufficiently to re-start the engine. An overheated engine will score the cylinder walls, burn out connecting rod and crankshaft bearings, also warp pistons and valves. The cause of the overheating condition will have to be remedied before the engine is re-started. See *Engine Overheats paragraph in Troubles, Causes and Remedies section.*

(On next revision, include in TE, TF manual)

STARTING

The engine, less electric starter, is started by applying the crank as shown in *Fig. 3* and pulling up briskly on the crank in a clockwise direction. **Do not** attempt to spin the engine with the starting crank. If the engine does not start on the first pull up of the crank re-engage the crank and repeat the operation.

WARM-UP PERIOD

When starting a gasoline engine for its days work, the engine should be allowed to warm up to operating temperature, before the load is applied. This requires only a few minutes of running of the engine at moderate speed.

Racing an engine or gunning it, to hurry the warm-up period, **is very destructive** to the polished wearing surfaces on pistons, rings, cylinders, bearings, etc., as the proper oil film on these various surfaces cannot be established until the oil has warmed up and become sufficiently fluid. This is especially important on new engines and in cool weather.

Racing an engine by disconnecting the governor, or by doing anything to interfere with the governor control of the speed of the engine, **is extremely dangerous**. Quite naturally the operator of the engine desires to get all possible power out of an engine, and the engine manufacturer does his best to supply this want, but if all of this power is used merely to speed up the engine, without any load being imposed upon it, dangerously high speeds will result.

The governor is provided as a means for controlling the engine speed to suit the load applied, and also as a safety measure to guard against excessive speeds, which not only overstrain all working parts, but which might cause wrecking of the engine, and possible injury to bystanders.

All parts of the engine are designed to safely withstand any speeds which might normally be required, but it must be remembered that the stresses set up in rotating parts, increase with the square of the speed. That means that if the speed is doubled the stresses will be quadrupled, and if the speeds are trebled the stresses will be nine times as great.

Strict adherence to the above instructions cannot be too strongly urged, and greatly increased engine life will result as a reward for these easily applied recommendations.

RESTORING COMPRESSION

On a new engine or on one which has been out of operation for some time, the oil may have drained off the cylinder so that compression will be weak. This may cause difficulty in starting. To remedy this condition, remove the spark plugs and pour about a fluid ounce of crankcase oil through the spark plug hole into each cylinder.

Turn the engine over several times with the starting crank to distribute the oil over the cylinder wall. Then replace the spark plugs and compression should be satisfactory.

TO STOP ENGINE

Engines, less house, have a lever type stop switch on the side of the magneto. On these, to stop engine, depress lever and hold down until engine stops. See *Fig. 1*. Others with house have an ignition switch on front panel of house as shown in *Fig. 2*. On these, to stop engine with magneto ignition, pull out the switch; with battery ignition, push in the switch.

If the engine has been running hard and is hot, do not stop it abruptly from full load, but remove the load and allow engine to run idle at 1000 to 1200 R.P.M. for three to five minutes, depending on how hot the engine has been. This will reduce the internal temperature of the engine much faster than stopping the engine, and of course the external temperature, including the manifold and carburetor will also reduce faster, due to the air circulation from the flywheel.

Two main troubles resulting from abrupt shutting off a hot engine are vapor lock and dieseling. Vapor lock will prevent the flow of fuel in the fuel lines and carburetor passages, which will result in hard starting of the engine. This can be overcome by choking the engine when cranking or waiting until the engine has cooled off sufficiently to overcome the vapor lock.

Dieseling, is caused by the carbon and lead deposits in the cylinder head being heated up to such an extent that they continue to fire the engine and keep it running after the ignition has been shut off. By idling the engine, as previously mentioned, the carbon and lead deposits cool off, break up and will blow out thru the exhaust. Have the carburetor throttle partially open when engine is shut off.

SAFETY PRECAUTIONS

Never fill fuel tank while engine is in operation or hot, as danger from fire would be incurred.

Never operate engine in a closed building unless the exhaust is piped outside. This exhaust contains carbon monoxide, a poisonous, odorless and invisible gas, which if breathed into the lungs would cause serious illness and possible death.

Never make adjustments on machinery while it is connected to the engine, without first removing the ignition cables from the spark plug. Turning over the machinery by hand during adjusting or cleaning might start the engine, and machinery with it, causing serious injury to the operator.

Always keep all parts of the engine clean. This will prolong engine life, and give more satisfactory operation.

Every 4 to 8 hours depending on dust conditions, check air cleaner and change oil. See *Page 8*.

Every 8 hours check crankcase oil level. Keep filled to **full** mark on oil gauge sabre, but no more. See *Fig. 4*.

Every 50 hours drain crankcase and refill with fresh oil. See *Lubrication, Pages 6 and 8*.

TROUBLES CAUSES AND REMEDIES

Three prime requisites are essential to starting and maintaining satisfactory operation of gasoline engines. They are:

1. A proper fuel mixture in the cylinder.
2. Good compression in the cylinder.
3. Good spark, properly timed, to ignite the mixture.

If all three of these conditions do not exist the engine cannot be started. There are other factors which will contribute to hard starting; such as, too heavy a load for the engine to turn over at a low starting speed, a long exhaust pipe with high back pressure, etc. These conditions may affect the starting, but do not necessarily mean that the engine is improperly adjusted.

As a guide to locating any difficulties which might arise the following causes are listed under the three headings: **Fuel Mixture**, **Compression**, and **Ignition**.

In each case the causes of trouble are given in the order in which they are most apt to occur. In many cases the remedy is apparent, and in such cases no further remedies are suggested.

STARTING DIFFICULTIES

FUEL MIXTURE

No fuel in tank or fuel shut-off valve closed.

Fuel pump diaphragm worn out, so pump does not supply carburetor with fuel.

Carburetor not choked sufficiently, especially if engine is cold. See 'Choke', Page 10.

Water, dirt, or gum in gasoline interfering with free flow of fuel to carburetor.

Poor grade or stale gasoline that will not vaporize sufficiently to form the proper fuel mixture.

Carburetor flooded, caused by too much choking especially if engine is hot. See 'Choke', Page 10.

Dirt or gum holding float needle valve in carburetor open. This condition would be indicated if fuel continues to drip from carburetor with engine standing idle. Often tapping the float chamber of the carburetor very lightly with the wood handle of a screw driver or similar instrument will remedy this trouble. Do not strike carburetor with any metal tools, it may be damaged. Also if the mixture in the cylinder, due to flooding, is not too rich to start the engine, starting should be tried, as it will usually correct the trouble. In this case the choke should be left open.

If, due to flooding, too much fuel should have entered the cylinder in attempting to start the engine, the mixture will most likely be too rich to burn. In that case the spark plugs should be removed from the cylinders and the engine then turned over several times with the starting crank, so the rich mixture will be

blown out through the spark plug holes. The choke on the carburetor should of course be left open during this procedure. The plugs should then be replaced and starting tried again.

To test for clogged fuel line, loosen fuel line nut at carburetor slightly. If line is open, fuel should drip out at loosened nut.

COMPRESSION

If the engine has proper compression, considerable resistance will be encountered in the pull on the starting crank on compression strokes. If this resistance is not encountered, compression is faulty. Following are some reasons for poor compression:

Cylinder dry due to engine having been out of use for some time. See 'Restoring Compression', Page 15.

Loose or broken spark plug. In this case a hissing noise will be heard in cranking engine, due to escaping gas mixture on compression stroke.

Damaged cylinder head gasket or loose cylinder head. This will likewise cause hissing noise on compression stroke.

Valve stuck open due to carbon or gum on valve stem. To clean valve stems, see 'Valves', Page 22.

Valve tappets adjusted with insufficient clearance under valve stems. See 'Valve Tappet Adjustment', Page 23.

Piston rings stuck in piston due to carbon accumulation. If rings are stuck very tight this will necessitate removing piston and connecting rod assembly and cleaning parts. See 'Piston and Connecting Rod' Page 20.

Scored cylinders. This will require reboring of the cylinders and fitting with new pistons and rings. If scored too severely an entirely new cylinder block may be necessary.

IGNITION

See 'Magneto Ignition Spark' Page 10 or 'Distributor-Battery Ignition' Page 11. No spark may also be attributed to the following:

Ignition cable disconnected from magneto or spark plugs.

Broken ignition cables, causing short circuits.

Ignition cables wet or oil soaked.

Spark plug insulators broken.

Spark plugs wet or dirty.

Spark plug point gap wrong. See Page 14.

Condensation on spark plug electrodes.

Magneto or Distributor breaker points pitted or fused.

Magneto or Distributor breaker arm sticking.

Magneto or Distributor condenser leaking or grounded.

Spark timing wrong. See 'Magneto Timing', Page 10, or 'Distributor-Battery Ignition', Page 11.

ENGINE MISSES

Spark plug gap incorrect. *See Page 14.*

Worn and leaking ignition cables.

Weak spark. *See 'Magneto Ignition Spark', Page 10, or 'Distributor-Battery Ignition', Page 11.*

Loose connections at ignition cable.

Magneto or Distributor breaker points pitted or worn.

Water in gasoline.

Poor compression. *See 'Compression', Page 16.*

ENGINE SURGES OR GALLOPS

Carburetor flooding.

Governor spring hooked into wrong hole in lever. *See 'Governor', Page 23.* Governor rod incorrectly adjusted. *See 'Governor', Page 23.*

ENGINE STOPS

Fuel tank empty.

Water, dirt or gum in gasoline.

Gasoline vaporized in fuel lines due to excessive heat around engine (Vapor Lock).

Vapor lock in fuel lines or carburetor due to using winter gas (too volatile) in hot weather.

Air vent hole in fuel tank cap plugged.

Engine scored or stuck due to lack of oil.

Ignition troubles. *See 'Ignition', Page 16.*

ENGINE OVERHEATS

Crankcase oil supply low. Replenish immediately.

Ignition spark timed wrong. *See 'Magneto Timing', Page 10, or 'Distributor-Battery Ignition', Page 11.*

Low grade of gasoline.

Engine overloaded.

Restricted cooling air circulation.

Part of air shroud removed from engine.

Dirt between cooling fins on cylinder head.

Engine operated in confined space where cooling air is continually recirculated, consequently becoming too hot.

Carbon in engine.

Dirty or incorrect grade of crankcase oil.

Restricted exhaust.

Engine operated while detonating due to low octane gasoline or heavy load at low speed.

ENGINE KNOCKS

Poor grade of gasoline or of low octane rating. *See 'Fuel', Page 9.*

Engine operating under heavy load at low speed.

Carbon or lead deposits in cylinder head.

Spark advanced too far. *See 'Magneto Timing' Page 10 or 'Battery Ignition Distributor', Page 11.*

Loose or burnt out connecting rod bearing.

Engine overheated due to causes under previous heading.

Worn or loose piston pin.

ENGINE BACKFIRES THROUGH CARBURETOR

Water or dirt in gasoline.

Engine cold.

Poor grade of gasoline.

Sticky inlet valves. *See 'Valves', Page 22.*

Overheated valves.

Spark plugs too hot. *See 'Spark Plug', Page 14.*

Hot carbon particles in engine.

DISASSEMBLING AND REASSEMBLING ENGINES

Engine repairs should be made only by a mechanic who has had experience in such work. When disassembling the engine it is advisable to have several boxes available so that parts belonging to certain groups can be kept together, such as, the cylinder head screws and etc. Capscrews of various lengths are used in the engine, therefore great care must be exercised in reassembly so that right screws will be used in the various places, otherwise damage may result.

Tighten the capscrews and nuts of the manifold, cylinder head, gear cover, engine base, connecting rods, cylinder block, main bearing plate and the spark plugs to the specified torque readings indicated in the following paragraphs of reassembly.

With the disassembling operations, instructions on reassembling are also given, as often, it will not be necessary to disassemble the entire engine. If it is desired to disassemble the entire engine the reassembly instructions can be looked up later under the headings of the various parts.

While the engine is partly or fully dismantled, all of the parts should be thoroughly cleaned. Remove all accumulated dirt between the fins on cylinder and head.

ACCESSORIES

Remove the muffler and disconnect the governor control, choke control, ignition switch, fuel lines and if an electric starter and generator are used, these should also be removed.

SHEET METAL HOUSE

With engines enclosed in a sheet metal house, the top or canopy should be removed by taking out the screws holding it to the end panels.




Fig. 15

148478C

FRONT PANEL

Remove the air cleaner and bracket, the flywheel screen and the four round head screws which support




Fig. 16

148477C

the panel to the side rails. The front house panel can then be removed as shown in Fig. 15.

REAR PANEL AND FUEL TANK

The fuel tank assembly is removed by taking out the six screws which hold it to the rear panel. The rear house panel can then be removed by taking out the screw holding it to the cylinder block, engine base and side rails. See Fig. 16.




Fig. 17.

148497C

FLYWHEEL

Loosen the flywheel nut with a monkey wrench or 1-3/8" open end wrench as shown in Fig. 17. Do not remove the flywheel nut, but unscrew it about two or three turns.

The flywheel is mounted to a taper on the crankshaft. Take a firm hold on the flywheel fins, pull outward and at the same time strike the end of the flywheel




Fig. 18

189165C

nut with a babbitt hammer. See Fig. 18. The flywheel will slide off the taper of the crankshaft and can be removed after the flywheel nut is removed. Striking the end of the flywheel nut instead of directly on the crankshaft will prevent serious damage to the threads at the end of the shaft. Also, do not use a hard hammer as it may ruin the crankshaft and bearings. When reassembling the flywheel, be sure the Woodruff key is in position on the shaft and that the keyway in the flywheel is lined up accurately with the key.




Fig. 19

148495C

FLYWHEEL SHROUD

The three capscrews which mount the flywheel shroud to the gear cover and the six screws to the cylinder shrouding must be removed to disassemble flywheel shroud from engine. See Fig. 19.

SIDE MOUNT FUEL TANK

If it is necessary the side mount fuel tank and bracket be disassembled, loosen the tank strap screws and remove the tank. This will make the four screws for mounting the tank bracket to the crankcase and engine base accessible. Otherwise, just remove the two screws holding the bracket to the crankcase and remove the tank and bracket assembly along with the engine base when it is removed.

CARBURETOR AND MANIFOLD

Remove the cotter pin from the governor control rod and pull the rod from the control lever. Take out the two capscrews which hold the air cleaner connection bracket to the gear cover and remove the two nuts and square washers from the manifold studs. The complete carburetor, manifold and air cleaner connection




Fig. 20

148490C

bracket can be removed as a complete unit, shown in Fig. 20.

In reassembly, tighten the nuts for mounting the manifold to 26 foot pounds torque. Tightening beyond specification may cause the square washers to crack.

CYLINDER HEAD

Remove the cylinder head cover, heat deflector and side shroud. If it is necessary to regrind valves or do work on the piston rings or connecting rods, the cylinder head will have to be removed. All the cylinder head screws are plainly in view and can be easily removed. Screws of different lengths are used but these can be properly reassembled according to the various lengths of cylinder head bosses. Before reassembling the cylinder head, all carbon and lead deposits must be removed. It is recommended that a new cylinder head gasket be used in reassembly as the old gasket




Fig. 21

148494C

will be compressed and hard, and it may not seal properly. Tighten cylinder head screws to 22 to 24 foot pounds torque.

GEAR COVER

Disconnect the governor linkage and oil line. Remove the governor, magneto and the gear cover mounting screws.

In reassembly, tighten capscrews to 16 to 18 foot pounds torque.

Screw a 5/16"-18 thread capscrew, having a 1-3/4" minimum length of thread, into one of the flywheel shroud mounting holes, see Fig. 21. Then, by lightly tapping the gear cover through the magneto mounting hole, the gear cover will come off without damage to the dowel pins. Pull out camshaft thrust plunger and spring to prevent losing them.




Fig. 22

148489C

CAMSHAFT GEAR

Remove the three capscrews which hold the gear to the end of the camshaft and pry it off with a screw driver or similar wedge tool. Note that the mounting holes in the camshaft gear are staggered in such a manner that the gear can be assembled to the shaft only one way which will automatically time the gear to the shaft. See *Timing Gear Train*, Fig. 22. The gear cover spacer plate can now be removed.

ENGINE BASE AND OIL PUMP

Be sure and drain oil from engine base. Take out 8 capscrews which mount engine base to crankcase, then turn engine on its side and take out the two cap




Fig. 23

148479C

screws from the bottom that hold the base to the case. Remove engine base as shown in Fig. 23.

In reassembly, tighten capscrews to 22 to 24 foot pounds torque.

Dismantle the oil pump by taking out the three capscrews which hold it to the crankcase. See Fig. 23. When servicing oil pump, be sure all ball checks and other parts are reassembled in same position as when taken apart. See Fig. 3.




Fig. 24

148485C-1

Before assembling oil pump to crankcase, fill base partially with engine oil and work pump plunger up and down, see Fig. 24, to test if pump is operating properly.

When assembling pump to crankcase, be sure that the plunger rod is in position. Install the oil pump cup, washer and strainer screen over the pump inlet before the engine base is mounted to the crankcase.

PISTONS AND CONNECTING RODS

After removal of engine base and oil pump, the connecting rods will be accessible. Remove the palnuts

and hexagon nuts, then by tapping the ends of the bolts lightly, being careful not to mar the threads, the connecting rod cap can be freed from the bolts. The rod with the piston can now be pushed up through the cylinder. Be careful not to score the crankshaft journals, by allowing the rod bolts to strike or scrape across them, when removing the connecting rod and piston assemblies. Replace the caps on the rods immediately so that they are in the correct position for reassembly, being sure that the shims are in place before the cap is put on. A number is stamped on the side of the rod and cap to match each connecting rod with its corresponding cap. These numbers must be on the same side of the connecting rod in reassembly. See Fig. 25.




Fig. 25

148483C

When assembling piston to connecting rod, the split side of the piston should be on the opposite side of the rod to the oil hole in connecting rod cap. See Fig. 3. The connecting rods are assembled into the engine with the oil hole in the cap pointing away from the camshaft side of the engine. See Fig. 25.

Be sure piston and connecting rod assemblies are put back into the same bore from which they were removed. Use a suitable ring compressor in reassembly and stagger the piston ring gaps 90° apart around the piston. Oil the pistons, rings, wrist pins, rod bearings and cylinder walls before assembly.

Tighten connecting rod nuts to 22 to 24 foot pounds torque, then install 'Pal' lock-nuts and tighten with wrench ¼ turn beyond 'finger-tight' position.

PISTON RINGS

Install rings by placing the open end of the ring on piston first, as shown in Fig. 26. Spread ring only far enough to slip over piston and into correct groove, being careful not to distort ring.

The scraper ring and oil ring must be installed on the piston with the scraper edge down, otherwise oil pumping and excessive oil consumption will result. See Fig. 27.




Fig. 26

71152C




Fig. 27

92200C-1

PISTON, RING AND ROD CLEARANCES CHART

Piston to Cylinder at Piston Skirt		.004 to .0045"
Piston Ring Gap		.014 to .024"
Piston Ring Side Clearance in Grooves	Top Ring	.002 to .0035"
	2nd Ring	.001 to .0025"
	Scraper Ring	.001 to .0025"
	Oil Ring	.0025 to .004"
Connecting Rod to Crank Pin	Diameter	.0007 to .002"
	Side	.004 to .010"
Piston Pin to Connecting Rod Bushing		.0005 to .001"

CYLINDER BLOCK

The cylinder block assembly can be removed by taking off the six nuts which hold the block to the crank case studs. See Fig. 28.

In reassembly, clean all dirt and other deposits from fins. If the cylinders are worn more than .005 inch oversize, they should be reground and fitted with oversize pistons and rings. This work should be done at an authorized service station.

Tighten cylinder block mounting nuts to 32 to 34 foot pounds torque.




Fig. 28

148486C




Fig. 29

194059C

VALVES

Remove the valve tappet inspection plate. Compress the valve springs with a standard automotive type valve lifter. We recommend a No. 358 valve lifter manufactured by KD Tools of Lancaster, Penn., or equivalent. See Fig. 29. Insert a rag in the opening at the bottom of the valve chamber so the valvespring seat retaining locks do not fall into the engine crankcase. Remove the valve spring seat retaining locks, seats, springs, valves and clean these, as well as the ports and guides, of all carbon and gum deposits. Tag each valve so that in reassembly they will be mounted in the same guide they were removed from.

The valve face is ground at 45° to the vertical center line of the valve stem and the valve seat insert should also be ground at a 45° angle. After grinding, valves and inserts should be lapped with a suitable lapping compound or they will leak due to improper

seating within the first few hours of operation. After valve seats have been cleaned, apply lapping compound to the valve face and put the valves back into their guides. Lap the valves by rotating them back and forth with a reciprocating advancing valve tool. Occasionally lift the valves and reseal them in a different position to insure a uniform seat which will show entirely around the valves. After valves have been lapped in evenly, remove them from the block and wash the valves and block thoroughly with gasoline or kerosene.

The valve stems should have a clearance of .003" to .005" in the guides. When the clearance becomes .007", the guides should be reamed and fitted with valves that have a .004" oversize valve stem. Later Model Engines have replaceable valve guides thus eliminating the necessity of using valves with oversize stems, as the worn guides can be driven out and replaced with new ones.




Fig. 30

148494C

CRANKSHAFT

To remove the crankshaft, first remove the oil slinger from the flywheel end of the shaft and take out the four cap screws holding the main bearing plate in place at the take-off end of the crankshaft. The main bearing plate can then be pried off and the crankshaft removed from that end of the crankcase as shown in Fig. 30.

Be sure to keep the gaskets on the main bearing plate in place, since they are necessary to give the proper end play to the Timken main bearings on the crankshaft. This end play should be .001 to .004 inch when engine is cold. There is practically no wear in the Timken roller bearings so that no readjustment is necessary after proper assembly.

When reassembling crankshaft, the timing marks on the crankshaft gear and the camshaft gear must match up, as shown in Fig. 22, otherwise engine will not operate properly or if timing is off considerably, engine will not run at all.

Mount main bearing plate in the correct position in reassembly. The word 'TOP' is cast on the outside of the plate, and should be mounted in this position. Tighten main bearing plate cap screws to 24 to 26 foot pounds torque.




Fig. 31

148492C

CAMSHAFT

Pull the valve tappets outward so as to clear the cams of the camshaft as it is removed from the crankcase, shown in Fig. 31. When replacing, be sure the spring and thrust plunger, see Fig. 21, are in place in the end of the camshaft, as these hold the camshaft in position endwise.



Fig. 32

148488C

VALVE TAPPETS

The valve tappets are taken out after the camshaft is removed. In reassembly, the tappets must of course be inserted in proper position in crankcase, before the camshaft is assembled.

After the cylinder block assembly has been mounted to the crankcase, the tappets should be adjusted. See Fig. 32. With the tappets in their lowest positions, engine cold, the clearance should be:

Inlet and Exhaust Valves, .011" to .013", including Stellite Exhaust Valves.

Engines having Stellite exhaust valves and inserts are designated as Models TED and TFD. Carefully check the model designation on name plate when adjusting valve tappet clearance.

OIL SPRAY NOZZLE

The oil spray nozzle is installed so that both metered holes can be seen when looking into the bottom of the crankcase. When positioned correctly, the flats on the hex body of the nozzle will be parallel with the top and bottom machined surfaces of the crankcase. The end of the spray nozzle should extend about 1½ inches from the boss it is screwed into, or so that the restricted discharge holes line up with the crankshaft centerline when it is installed. See oil spray nozzle, Fig. 3 and Fig. 4.

GOVERNOR

The centrifugal flyball governor rotates on a stationary pin driven into the upper part of the timing gear cover, and the governor is driven off the camshaft gear at crankshaft speed.

The flyweights are hinged to lugs on the gear. Hardened pins on the flyweights bear against the flanged sliding sleeve, moving it back and forth as the flyweights move in or out. The motion of the sleeve is transmitted through a ball thrust bearing to the governor lever, which in turn is connected to the carburetor throttle lever. A spring connected to the governor lever tends to hold the governor flyweights to their inner position, also to hold the carburetor throttle open. As the engine speed increases, the centrifugal force in the flyweights acts against the spring and closes the throttle to a point where the engine speed will be maintained practically constant under varying load conditions. This speed can be varied to suit conditions by adjusting the governor spring to suit.

The control rod from the governor to carburetor must be adjusted to the proper length otherwise the governor action will be faulty. With the engine at rest the governor spring will hold the flyweights 'in', and the control rod must be of such length as to hold the carburetor throttle wide open at that point. The ac-




Fig. 33

148481C

curacy of this adjustment can be tested by disconnecting the rod from the governor lever, and then pushing the rod toward the carburetor as far as it will go. This will open the throttle wide. The bent end of the rod should then exactly register with the hole in the governor lever. See Fig. 33. If it does not, the rod should be screwed into or out of the swivel block on the carburetor lever, until the above mentioned registry is attained. The rod should then be again connected to the governor lever. If this adjustment is not made accurately the governor may cause the engine speed to surge or otherwise be unsatisfactory.

The governor can be disassembled from the engine by first removing the governor housing, after which the entire governor can be withdrawn from the stationary pin. The construction of the governor can be best seen from the sectional drawing of the engine, Fig. 3.

The governor lever is furnished with 12 holes, as shown in the following table, for attaching the governor spring. It is very important that the spring is hooked into the proper hole to suit the speed at which the engine is operated. A table is given herewith showing the full load and no load speeds of the engine and the hole corresponding thereto. The full load speed will be from 150 to 125 revolutions less than the no load speed.

LOAD R.P.M.	NO LOAD R.P.M.	HOLE NO.	GOVERNOR LEVER
1400	1550	2	
1500	1650	3	
1600	1725	3	
1700	1850	4	
1800	1925	4	
1900	2025	5	
2000	2150	6	
2100	2225	6	
2200	2350	7	
2300	2425	7	
2400	2550	8	
2500	2650	9	
2600	2725	9	

As an example, if the engine is to be operated at 2150 revolutions per minute without load, the spring should be hooked into the 6th hole in the governor lever and the spring tension adjusted by means of the adjusting screw on the spring to run 2150 revolutions per minute. The speed at full load will then be approximately 2000 revolutions per minute.

CLUTCH AND REDUCTION GEARS

CLUTCH

The clutch furnished with these models of engines is of the disc type running in oil. Use the same grade




Fig. 34

140451C

of oil in the clutch as is used in the crankcase of the engine. The oil should be filled through the inspection plate opening, to the height of the oil level plug. Approximately a pint of oil is required. See Fig. 34.

CLUTCH ADJUSTMENT

If the clutch begins to slip it should be readjusted, otherwise it would become overheated and damaged.



Fig. 35

208067C

First remove the clutch inspection plate. This will expose the notched adjusting collar. Release clutch engaging lever. Turn adjusting collar in clockwise direction with a screw driver or similar instrument. See Fig. 35. The collar should be turned one notch at a time until a definite pressure is felt on the clutch lever when clutch is being engaged. Then replace inspection plate, being careful that the gasket fits properly and is not broken.

On the clutch reduction gears, there is a no inspection plate directly over the clutch. A pipe plug is furnished, however, and the clutch adjustment is made through the pipe plug hole. See Fig. 36.

STORAGE OF ENGINE FOR WINTER

When the season's work is completed, the following instructions should be carried out very carefully to protect the engine over winter.

The outside of the engine, including the cooling fins on the cylinders and heads, should be thoroughly cleaned of all dirt and other deposits.

The air cleaner at the carburetor intake should be thoroughly cleaned of all oil and accumulated dust and sediment removed from the oil cup at the bottom of the cleaner.

To protect the cylinders, pistons, rings and valves and keep them from rusting and sticking, a half and half mixture of kerosene and good gas engine oil, (the same kind of oil as used in the crankcase of the engine), should be injected into the pipe tap opening on the intake manifold while the engine is warm and running at moderate speed. About a quarter of a pint is necessary, or enough so that a heavy bluish smoke will appear at the exhaust. The ignition switch should then be shut off and the engine stopped. This operation will give a coating of oil on the above mentioned parts, protecting them from the atmosphere.

All old used oil should be drained from the crankcase while the engine is warm, as the oil will then flow more freely than when cold.

Drain fuel system, including gasoline lines, carburetor, fuel pump and tank of all gasoline to prevent lead and gum sediment interfering with future operation.

All exposed unpainted metal parts should be coated with grease or heavy oil.

Before starting the engine again the next season, the crankcase drain plug should again be removed, so that any condensation, which may have collected during the winter, may be drained before new crankcase oil is added.

A good plan, and one that is recommended is to remove the crankcase oil base in the spring before starting the engine for the new season, and scrubbing off all sediment which may have collected there.

When replacing the engine base, a new gasket should be used.

Be sure to fill the crankcase with a good quality of crankcase oil to the high level point, before starting the engine. Do not use any oil heavier than SAE No. 30. Also be sure to put oil to the proper level in the air cleaner.

It is also recommended to use new spark plugs at the beginning of the next season, especially if the engine has given considerable service.

Refuel engine and follow the starting instructions as shown on preceding pages of this manual.

It is highly recommended that machines be stored inside a building through the winter. If this is not possible, the engine should be protected from snow and ice by a proper covering.




Fig. 36

104575C




Fig. 37

76090C


REDUCTION GEARS

Reduction gears are furnished with several different ratios, some with spur gears, others with chains. All are of the same general design, except that some are furnished with clutches, others without. These reduction gears require the same grade of oil as is used in the crankcase of the engine. For various installations these gears are assembled to the engines in various positions. Several plugs are furnished on these reduction gears so that the lubrication may be properly taken care of regardless of the position of the installation. For instance, there will always be one plug on top to be used for filling oil. There will always be one plug below for draining oil, and there will be one plug on the side slightly above the bottom, to be used as an oil level plug. See Fig. 37.

The oil should always be filled when the engine is at rest. When the oil becomes dirty it should be drained, while the engine is hot, and fresh oil added. The frequency at which these oil changes should be made depends entirely on the kind of service in which these gears are used, but even with light service the change should be made at least once every five hundred hours of operation, adding sufficient oil between changes to keep the oil up to the oil level plug.

CA-62-Etc. CRANKSHAFT JOURNAL DIMENSIONS

For Engine Models TE, TF and TH



Diameter - 1.751
- 1.750 inch

Length - 1.130
- 1.125 inch

Radius - 1/8 inch

REPAIR PARTS LIST

READ THESE INSTRUCTIONS BEFORE ORDERING PARTS

THE MODEL, SPEC AND SERIAL NUMBER OF YOUR ENGINE, SHOWN ON THE NAME PLATE ATTACHED TO THE AIR SHROUD, MUST BE GIVEN WHEN ORDERING PARTS.

FILL IN THE ABOVE INFORMATION ON THE PHOTO OF THE NAME AND INSTRUCTION PLATE SO THAT IT WILL BE AVAILABLE TO YOU WHEN ORDERING PARTS.

MODEL	<input type="text"/>	WISCONSIN <i>air cooled</i>	R.P.M.	<input type="text"/>
SERIAL NO.	<input type="text"/>		SIZE	<input type="text"/>
			SPEC. NO.	<input type="text"/>

OPERATING INSTRUCTIONS

Fill crankcase with good clean gas engine oil to "FULL" mark on oil sabre, for temperatures of 40°F. or over use S.A.E. No. 30 oil, for temperatures of 5°F. to 40°F. use S.A.E. No. 20 oil, for colder weather use S.A.E. No. 10W oil. Fill fuel tank with good clean gasoline of the REGULAR grade.

TO START ENGINE:

1. Open gasoline shut-off cock.
2. Magneto switch should be in "ON" or running position. (Push button type switch is normally in "ON" position, knurled button switch is "ON" when turned clockwise.)
3. Close choke on carburetor, choke must be open after engine starts.
4. Crank engine, with hand crank or starter rope. Repeat if necessary.

TO STOP ENGINE
Shut off magneto switch. (With push button type switch, hold down until engine stops.)

CARE IMPROVES SERVICE, REDUCES REPAIRS.
Drain old oil and refill with new oil after every 50 hours of operation. Spark plug gap should be .030 inch. A good air cleaner on carburetor must be used and cleaned daily. Firing order of cylinders 360°. No. 1 cylinder is nearest flywheel. **KEEP ENGINE CLEAN AT ALL TIMES.**

WISCONSIN MOTOR CORPORATION — MILWAUKEE, WISCONSIN - U.S.A.

SD-153

193683C-2

TO INSURE PROMPT AND ACCURATE SERVICE, THE FOLLOWING INFORMATION MUST ALSO BE GIVEN.

1. State exactly, quantity of each part and part number.
2. State definitely, whether parts are to be shipped by express, freight or parcel post.

SERVICE FACILITIES

Approved engine service stations, located throughout the U.S. and foreign countries, have been carefully selected by the WISCONSIN MOTOR CORPORATION in order to assure complete and efficient repair and inspection service to owners of Wisconsin Air Cooled Engines. These service stations, equipped and trained for complete engine repair, also stock parts to facilitate immediate delivery for all Wisconsin Air Cooled Engines.

A DIRECTORY OF SERVICE STATIONS CAN BE FOUND IN THE BACK OF THIS MANUAL.

PARTS RETURNED FOR CREDIT

Before returning any parts, write a letter to the company from whom the parts were purchased, giving an exact list and description of the materials, why you wish to return them, whether for repairs, credit, or replacement, and also the model, specification and serial numbers of the engine from which the parts were taken. If authority is granted for their return, transportation charges must be prepaid and sender's name marked on the outside of the box or package.

MODELS TE AND TF




Fig. 44, EXPLODED VIEW OF ENGINE

Refer to figure numbers for break down of parts.

151217C-1

PARTS FOR MODELS TE AND TF ENGINES




Fig. 45, CYLINDER BLOCK ASSEMBLY

151297C-1




Fig. 46, CARBURETOR, MANIFOLD AND AIR CLEANER GROUP

Parts are identified by reference number. See parts list for correct part number.

151299C-3

MODELS TE AND TF




Fig. 47, CRANKCASE, GEAR COVER, BASE AND MAGNETO GROUP

Parts are identified by reference number. See parts list for correct part number.

151300C-1




Fig. 48, CRANKSHAFT, PISTON AND CONNECTING ROD GROUP
 Parts are identified by reference number. See parts list for correct part number.

151295C

PARTS FOR MODELS TE AND TF ENGINES




Fig. 49, CAMSHAFT AND VALVE TAPPET GROUP

151294




Fig. 50, FUEL PUMP, OIL GAUGE AND OIL SPRAY NOZZLE GROUP

Parts are identified by reference number. See parts list for correct part number.

151293





Fig. 51, OIL PUMP ASSEMBLY

151292C-1



REF. NO. 252 COMPLETE GOVERNOR ASSEMBLY

Fig. 52, GOVERNOR ASSEMBLY

151296C-1

Parts are identified by reference number. See parts list for correct part number.

PARTS FOR MODELS TE AND TF ENGINES




Fig. 53, AIR SHROUDING AND FUEL TANK GROUP

151216C-1




Fig. 54, GASKET SET

Parts are identified by reference number. See parts list for correct part number.

PARTS LIST

MODELS TE and TF – 2 CYLINDER STANDARD ENGINE

ENGINES HAVING STELLITE EXHAUST VALVES AND INSERTS ARE DESIGNATED AS MODELS TED AND TFD.

The following parts are for a standard engine without house. If power unit house parts are required, refer to Page 42.

Ref. No.	Part Number		Description	No. Req.	Net Weight	
	TE	TF			Lbs.	Oz.
101	AA-85-S22	AA-86A-S22	CYLINDER BLOCK ASSEMBLY , standard..... Complete with valves, guides, springs, seats, locks and inserts. PC-110 Studs for mounting manifold must be ordered separately. AA-86-S22, replaced by AA-86A-S22.	1	30	
	AA-85-S19 (TED)	AA-86A-S19 (TFD)	CYLINDER BLOCK ASSEMBLY , complete with STELLITE exhaust valves and inserts, guides, springs, seats, locks, studs, inspection plate, gasket, screw and pin. AA-86-S19, replaced by AA-86A-S19.			
102	AB-100-B		CYLINDER HEAD AB-80-E Cylinder Head, replaced by AB-100-B.	1	2	13
		AB-100	CYLINDER HEAD AB-86 Cylinder Head, replaced by AB-100.	1	4	
103	DB-209		PISTON , standard size..... DB-187B-1 Piston, replaced by DB-209. DB-208 Piston, replaced by DB-209. NOTE: These pistons are interchangeable only in sets.	2		8
		DB-210	PISTON , standard size..... DB-190 Piston, replaced by DB-210, interchangeable only in sets. Pistons are also furnished .005", .010", .020", .030" oversize and semi-finished.	2		9
104	DR-19	DR-20	PISTON RING SET , standard size Consisting of:	1		5
105	DC-109	DC-112-A	OIL RING	2		1
106	DC-163	DC-125-2	COMPRESSION RING	4		1
107	DC-163-1	DC-210	SCRAPER RING DC-125-3, replaced by DC-210. Piston rings and ring sets are also furnished .005", .010", .020" and .030" oversize.	2		1
110	L-48-L (ZENITH No. 10627-B)	L-48-J (ZENITH No. 10595-C)	CARBURETOR , Zenith Model 161-7..... For engines with fuel pump.	1	2	15
	L-48L-1	L-48J-1 (ZENITH No. 11774)	CARBURETOR for engines with fuel pump and generator-distributor ignition			
	L-48-D (ZENITH No. 5-1548-B)	L-48-C (ZENITH No. 5-1329-C)	CARBURETOR , Zenith Model 161-7..... For power unit engines with gravity feed fuel system.	1	2	15
	L-48D-1	L-48C-1	CARBURETOR for power unit engines with generator-distributor ignition and gravity feed fuel system			
115	XD-148		SCREW , 5/16"-18 thread x 1-5/8" long, hexagon head..... For valve inspection cover plate, No. 1 cylinder.	1		2
		XD-21	SCREW , 5/16"-18 thread x 1-1/2" long, hexagon head..... For valve inspection cover plate, No. 1 cylinder.	1		2

Order parts from nearest **SERVICE STATION** shown in directory following parts list.

IMPORTANT: Always give Model, Specification and Serial Numbers as shown on name plate.

PARTS INTERCHANGEABLE ON MODELS TE AND TF

Ref. No.	Part Number	Description	No.		Net Wt.		Ref. No.	Part Number	Description	No.		Net Wt.	
			Req		Lb	Oz				Req		Lb	Oz
119	AD-41	VALVE STEM GUIDE for engines beginning with Serial No. 2247771	4		2		125	BB-126-A	OIL PAN and ENGINE BASE	1		21	
120	AE-75-B	VALVE, inlet and exhaust, standard	4		3			BB-126A-1	ENGINE BASE, for engine covered with sheet metal house (Has tapped holes for mounting house panels)			21	
	AE-75-D	STELLITE EXHAUST VALVE	2		3		126	BD-103B-S1	GEAR COVER ASSEMBLY	1		8	
		For TED and TFD engines. Valves are also furnished with .004" oversize stem.							Consisting of: 1 BD-103-B Gear cover 1 PF-25 Pipe plug 1 PF-52 Button 1 PH-299 Oil seal 1 SA-26 Plug 1 TC-388-2 Governor shaft BD-103-S1 Cover, replaced by BD-103B-S1.				
121	AF-49-A	VALVE SPRING, standard	4		2		127	BG-209	BEARING RETAINER PLATE	1		10	
	AF-51	VALVE SPRING, (1-31/32" approx. free length) for TED and TFD engines with Stellite exhaust valves	2		2		128	BG-224-S1	MAIN BEARING PLATE ASSEMBLY	1		4	8
122	AG-26	SEAT for valve spring	4		1			BG-224-S2	MAIN BEARING PLATE ASSEMBLY			5	
123	AH-9	LOCK for valve spring seat	4pr		1				Consisting of: 1 BG-224 Bearing plate 1 HF-261 Cork seal 1 ME-130-2 Main bearing cup 1 SD-43 Cork retainer				
124		CRANKCASE ASSEMBLY	1	30			130	BI-286-S1	AIR CLEANER BRACKET ASSEMBLY ..	1	1	10	
		Consisting of: 1 Crankcase 1 JK-50 Primer packing 1 PA-332 Primer stop pin 6 PC-337 Studs 1 PD-78 Nut 2 PE-3 Lockwashers 1 PE-46 Lockwasher 2 PF-18 Plugs 1 PM-163 Primer spring 1 QD-670 Gasket 1 RF-270 Elbow 1 RF-1196 Spray nozzle 1 RF-1199 Header tube 1 SA-10 Plug 1 SA-52 Plug 1 SA-92 Cover 1 TA-124 Primer shaft 1 TA-125 Primer handle 2 XD-6 Screws 1 XK-121 Plug							Consisting of: 1 BI-286 Bracket 1 LO-84 Breather assembly 1 PC-447 Stud				
		NOTE: The part number of the crankcase is stamped on the case in the location shown in Fig. 1. ORDER BY THIS NUMBER and by giving the Model, Specification and Serial Number of the engine.					131	BK-79-A	BRACKET for fuel tank	1	3	12	
								BK-80	FUEL TANK BRACKET			5	
							132		CRANKSHAFT ASSEMBLY	1	26	8	
									Consisting of: 1 Crankshaft 1 GA-36A-1 Gear 1 ME-71 Bearing, flywheel end 1 ME-130 Bearing, take-off end 1 PL-53 Key				
									NOTE: The part number of the crankshaft will be found stamped on the counterweight as illustrated in Fig. 2. ORDER BY THIS NUMBER and by giving Model Specification and Serial Number of the engine.				




Fig. 1 152521C




Fig. 2 152520C

Order parts from nearest **SERVICE STATION** shown in directory following parts list.
IMPORTANT: Always give Model, Specification and Serial Numbers as shown on name plate.

PARTS INTERCHANGEABLE ON MODELS TE AND TF

No. Req.	Net Lb.	Oz.	Part Number	Description	No. Req.	Net Wt.		Ref. No.	Part Number	Description	No. Req.	Net Wt.		
						Lb.	Oz.					Lb.	Oz.	
			DA-51B-S1	CONNECTING ROD ASSEMBLY Consisting of: 1 DA-51-B Connecting rod (not furnished separately). 1 HG-157A Bushing 2 PE-148 Bolts 2 PD-10 Nuts 2 PD-181 Palnuts 2 QA-114 Shims Connecting rods are also furnished .010", .020" and .030" undersize.	2	1	7	158	LO-83	OIL BATH AIR CLEANER , United Specialties No. T-12B12..... Service parts: United Specialties Part No 179B4 Cap and filter assembly A-7419 Mounting gasket..... 615A1 Filter gasket..... 176B8 Oil cup assembly..... LO-83, United Specialties No. B-13845—replaced by LO-83, United Specialties No. T-12B12, interchangeable as a unit only. The old LO-83, United Specialties No. B-13825 consists of: 10792 Cap B-13829 Filter unit B-13831 Oil cup A-7419 Base gasket	1	2	8	
			DE-65	PISTON PIN , standard size Piston pins are also furnished .010", .020" and .030" oversize.	2		3	158A 158B 158C 158D						
			EA-106	CAMSHAFT	1	3	6							
			F-61	VALVE TAPPET with lock screw FA-40-B Tappet—replaced by F-61.	4		4							
			GA-36A-1	CRANKSHAFT GEAR	1		14							
			GB-45A-2	CAMSHAFT GEAR	1	2	2	159	OPTIONAL LO-98	OIL BATH AIR CLEANER with pre-cleaner, U.S. No. 12C2 Service parts: U.S. Part Numbers. A-16380 Pre-cleaner cap assembly B-16382 Pre-cleaner body assembly 180B2 Air cleaner cap assembly A-11812 Wing nut for top..... 990A1 Wing nut on side 615B2 Rubber spacer gasket..... A-7421 Gasket for filter unit A-17936 Filter unit A-17752 Body assembly A-7419 Mounting gasket	1	5	2	
			GD-93C-1	MAGNETO GEAR	1		9	159A 159B 159C 159D 159E 159F 159G 159H 159J 159K						
			GD-100A-1	GOVERNOR GEAR GD-100-A Gear—replaced by GD-100A-1.	1		7							
			HF-261	CORK OIL SEAL	1		1							
			HG-157A-1	PISTON PIN BUSHING	2		1							
			HG-201	VALVE SEAT INSERT , standard	4		1							
			HG-201-D	STELLITE EXHAUST VALVE SEAT INSERT , for TED and TFD engines....	2		1							
			JK-50	'O' RING OIL SEAL	1		1	160	LO-84-C	BREATHER ASSEMBLY	1		2	
			JK-52	'O' RING OIL SEAL for governor cross shaft, beginning with engine Serial No. 1604246—replaces PH-318A Oil Seal and PF-118 Retainer—for engines to and including Serial No. 1604245. Not interchangeable unless complete TC-428-C Governor Cross Shaft and Lever Assembly, which includes JK-52 'O' Ring, is ordered.	1		1	161	LP-43	FUEL STRAINER (small) Tillotson No. OW-480-T Mounted to fuel pump inlet, beginning with engine Serial No. 1893058. LP-19-B Strainer (large) mounted to carburetor, for engines to and including Serial No. 1893057—replaced by LP-43, interchangeable if fuel line to carburetor is also changed.	1		3	
			KA-63B-1-S1	OIL PUMP BODY ASSEMBLY	1		6	162	LP-19-B	FUEL STRAINER (large) Tillotson No. OW-444 Mounted to fuel tank, for engines with electric starter. NOTE: See illustration in back of manual for service parts list of fuel strainers	1		9	
			KF-23-1	OIL PUMP PLUNGER KF-23 Plunger—replaced by KF-23-1.	1		2	163	LP-42-A LQ-28	FUEL PUMP , Blackstone No. GI-205..... REPAIR KIT for fuel pump NOTE: Refer to fuel pump instruction sheet in back of manual for maintenance and repair.	1		10 2	
			KF-24	OIL PUMP PUSH ROD	1		2	164	ME-38	CHECK BALL , for oil pump, 5/16" dia. steel	2		1	
			KF-25	PUSH ROD CAP	1		1	165	ME-71	MAIN BEARING ASSEMBLY Flywheel end. Consisting of: 1 ME-69-1 Bearing cup—Timken 414..... 1 ME-71-1 Bearing cone—Timken 420.....	1	1	14 12 2	
			KF-28	RETAINER for oil pump outlet ball..... SA-26-1—replaced by KF-28.	1		1	166 167						
			LC-266-A	INLET MANIFOLD	1	1	4	168	ME-130	MAIN BEARING ASSEMBLY Take-off end. Consisting of: 1 ME-130-1 Bearing cone—Timken 26881 1 ME-130-2 Bearing cup—Timken 26822A	1	1	4 13 7	
			LD-242	EXHAUST MANIFOLD	1	3	8	171	NC-145-G	FLYWHEEL	1	33		
			LJ-192	PIPE NIPPLE for muffler, 1/4" x 4 1/2" long, for open engine	1		10							
			LJ-188	PIPE NIPPLE for muffler, 1/4" x 6" long, for engine covered with sheet metal house	1		12							
			LK-5	HOSE CLAMP for air cleaner connection 1-5/8" I.D.	2		1							
			LL-92	HOSE CONNECTION for air cleaner.....	1		3							

(Continued)

Order parts from nearest **SERVICE STATION** shown in directory following parts list.
IMPORTANT: Always give Model, Specification and Serial Numbers as shown on name plate.

PARTS INTERCHANGEABLE ON MODELS TE AND TF

Ref. No.	Part Number	Description	No.		Net Wt.		Ref. No.	Part Number	Description	No.		Net Wt.	
			Req	Lb	Oz	Req				Lb	Oz		
	NC-145G-1-S1	FLYWHEEL for engines with electric starter. Includes: 1 GH-46 Ring gear 3 XE-17 Set screws NC-145B-1-S1—replaced by NC-145G-1-S1			34		201	PL-83	KEY for flywheel, No. 23 Woodruff	1			
172	PA-333	PIN for starting crank nut	1		1	203	PM-58	SPRING for oil pump plunger	1				
		PA-239 Pin—replaced by PA-333.				204	PM-75	SPRING for governor	1				
173	PA-332	PIN for fuel pump primer stop.....	1		1	205	PM-108	SPRING for camshaft thrust plunger.....	1				
		PA-281 Groov-pin—replaced by PA-332.				206	PM-163-A	SPRING for fuel pump primer handle	1				
174	PA-291	DOWEL PIN for gear cover to crankcase	2		1			PM-163 Spring—replaced by PM-163-A.					
175	PA-340	ROLL PIN for governor flyweights	2		1	207	PM-165-1	SPRING for oil pump outlet.....	1				
		XJ-47 Rivet—replaced by PA-340 roll pin						PM-162 and PM-165 Springs—replaced by PM-165-1.					
176	PB-148-S1	CONNECTING ROD BOLT ASSEMBLY ..	4		1	209	Q-21	GASKET SET (Fig. 54).....	1				
		Consisting of: 1 PB-148 Bolt 1 PD-10 Nut 1 PD-181 Palnut						Consisting of: 3 QB-75 1 QD-613-C 1 QD-661-A 1 QC-58-A 1 QD-616 1 QD-662-A 9 QD-487-A 1 QD-617 1 QD-663-A 1 QD-487-B 1 QD-638-A 1 QD-667 2 QD-612-A 1 QD-660 1 QD-670					
177	PB-169-A	VALVE TAPPET ADJUSTING SCREW.. For F-61 Tappet. PB-169 Adj. screw—replaced by PB-169A PB-147 Screw with PD-141 nut for obsolete FA-40-B tappet.	4		1	210	QA-114	CONNECTING ROD SHIM	4				
178	PC-110	STUD for manifold to cylinder block mounting	2		1	211	QB-75	GASKET for manifold mounting	3				
179	PC-337	STUD for cylinder block to crankcase mounting	6		1	212	QC-58-A	GASKET for carburetor mounting	1				
180	PC-447	STUD for air cleaner to bracket mounting	1		1	213	QD-487-A	GASKET for main bearing plate, .006" thick	9				
181	PD-173-A	NUT for governor adjusting screw.....	1		1	214	QD-487-B	GASKET for main bearing plate, .003" thick	1				
182	PD-181	PALNUT for connecting rod bolt, 5/16-24	4		1	215	QD-612-A	GASKET for valve inspection cover	2				
183	PE-59	WASHER for starting cranknut, 1" external Everlock.....	1		1	216	QD-613-C	GASKET for cylinder head	1				
184	PF-52	BUTTON for camshaft thrust plunger	1		1			QD-613-B for TE engine—replaced by QD-613-C.					
185	PF-101	CAMSHAFT THRUST PLUNGER	1		1	217	QD-616	GASKET for magneto mounting.....	1				
189	PG-314	CLIP for spark plug cables	1		1	218	QD-617	GASKET for cylinder block to crankcase	1				
190	PG-315	CLIP for mounting flywheel screen to shroud	4		1	219	QD-638-A	GASKET for governor housing	1				
191	PG-488	FUEL TANK STRAP NOTE: Early model engines had fuel tank mounted with steel binder strapping which is not serviceable. For replacement, order 2 each of PG-488 straps, XA-52 screws, PD-77 nut and PE-3 lock-washers.	2		8	220	QD-660	GASKET for gear cover to spacer	1				
						221	QD-661-A	GASKET for gear cover spacer to crankcase	1				
193	PH-299	CRANKSHAFT OIL SEAL in gear cover	1		2	222	QD-662-A	GASKET for engine base to crankcase ..	1				
194	PH-313-A	SHIM for governor bushing.....	1		1	223	QD-663-A	GASKET for oil pump to crankcase	1				
195	PH-356	CLAMP WASHER for manifold mounting..	2		1			QD-663 Gasket—replaced by QD-663-A.					
196	PH-387	SPACING WASHER for oil strainer	1		1	224	QD-667	GASKET for air cleaner bracket to gear cover	1				
197	PI-115F-1	SCREW for adjusting governor spring	1		2	225	QD-669	GASKET for breather (Part of LO-84 assembly).....	1				
198	PK-50-A	RETAINER for oil pump check ball..... PK-50 Retainer—replaced by PK-50-A.	1		1	226	QD-670	GASKET for fuel pump or pad cover mtg.	1				
199	PK-52	RETAINING RING for piston pin.....	4		1	227	RC-77-5	CAP for fuel tank	1				
200	PL-53	KEY for crankshaft gear, No. 8 Woodruff..	1		1	228	R-123	OIL FILLER and GAUGE ASSEMBLY .. Consisting of: 1 LJ-310 ½" Pipe Nipple, 1½" long .. 1 RB-86 Body	1				
								1 RC-106-S1 Cap and Gauge Assembly ..					
								R-114-9—replaced by R-123.					
						230	RD-107-A	OIL STRAINER	1				
								RD-107 Strainer—replaced by RD-107-A.					

Order parts from nearest **SERVICE STATION** shown in directory following parts list.
IMPORTANT: Always give Model, Specification and Serial Numbers as shown on name plate.

PARTS INTERCHANGEABLE ON MODELS TE AND TF

No. Req	Net Wt. Lb Oz	Part Number	Description	No. Req	Net Wt.		Ref. No.	Part Number	Description	No. Req	Net Wt.	
					Lb	Oz					Lb	Oz
1		RF-269	STRAIGHT FITTING 1-for oil line to governor housing. 1-in carburetor for fuel line. 1-in fuel strainer (when mounted to fuel tank).	3		1	250	SE-138-B	AIR SHROUD HEAT DEFLECTOR for engines beginning with Serial 1873091... SE-138 Deflector for engines to and including Serial 1873090, interchangeable with SE-138-B if SE-138-B cylinder shroud is used.	1		12
1		RF-270	ELBOW for 1/4" tubing nut..... 1-in fuel strainer. 1-in fuel pump outlet.	2		1	251	TA-126	FUEL PUMP PRIMER SHAFT and HANDLE ASSEMBLY With JK-50 'O' ring oil seal.	1		1
1		RF-270-4	RESTRICTED ELBOW FITTING 1 gov housing for oil line. RF-269-2 Straight fitting-replaced by RF-270-4 Elbow fitting.	1		1	252	T-96-S1	GOVERNOR ASSEMBLY Consisting of: 1 TC-391-A Thrust sleeve & bearing. 1 TC-422B-S1 Housing assembly. 1 TC-405-A Flyweight assembly.	1	2	12
1		RF-1196	OIL SPRAY NOZZLE 1 gov housing for oil line.	1		1	253	TC-322-A	GOVERNOR FLYWEIGHT	2		3
1		RK-170	C. SLING for crankshaft	1		2	254	TC-328	GOVERNOR FLYWEIGHT THRUST PIN	2		1
1		RK-178	CUP for oil strainer	1		1	255	TC-388-2	GOVERNOR SHAFT	1		2
1		RM-477	FUEL LINE , tank to strainer, 18" long.. Tubing with nuts. RM-450 Fuel line, 20" long-replaced by RM-477.	1		4	256	TC-389-1	GOVERNOR GEAR BUSHING	1		2
4		RM-849	OIL LINE , governor to crankcase, 6" long Tubing with nuts. RM-776 Oil line, 9 1/2" long-replaced by RM-849 but mount in upper tap of oil header tube in crankcase.	1		2	257	TC-391-B	GOVERNOR THRUST SLEEVE and BEARING	1		2
3		RM-1122	FUEL LINE , pump to carburetor, 6 1/2" long. Tubing with nuts	1		2	258	TC-405-A	GOVERNOR FLYWEIGHT ASSEMBLY .. Consisting of: 1 GD-100A-1 Gear 2 PA-340 Roll pin 1 PH-313-A Shim 2 TC-322-A Flyweights 2 TC-328 Pins 1 TC-389-1 Bushing TC-405 Flyweight assembly-replaced by TC-405-A.	1		1
1		RM-1206	SUCTION TUBE and ELBOW	1		3	259	TC-422B-S1	GOVERNOR HOUSING ASSEMBLY (Aluminum) Consisting of: 1 JK-52 'O' ring 1 PF-18 Plug 1 QD-638A Gasket 1 RF-270-4 Fitting 1 SA-52 Plug 1 TC-422-B Housing 1 TC-428-C Shaft and lever 1 VB-166 Yoke 1 XH-1 Pin TC-422-1-S1 and TC-422-2-S1 (cast iron) Housing assemblies-replaced by TC-422B-S1.	1		1
1		RM-1211	SUCTION TUBE for engines with electric starter (fuel strainer mounted to fuel tank)	1		3	260	TC-427-B	SUPPORT PIN for governor adjusting screw	1		2
1		SA-68	COVER PLATE for valve tappet inspection	2		2	261	TC-428-C	GOVERNOR CROSS SHAFT & LEVER. With JK-52 'O' ring-beginning with engine Serial No. 1249047. TC-428-A Shaft and lever-for engines to and including Serial No. 1249046.	1		2
1		SD-43	RETAINER for main bearing cork oil seal, take-off end	1		1	263	U-212	STARTING CRANK	1		7
1		SD-153	ENGINE INSTRUCTION and NAME PLATE	1		1	264	UC-75-S1	STARTING CRANK NUT ASSEMBLY Consisting of: 1 PA-333 Pin 1 UC-75 Nut	1		1
1		SE-3	FLYWHEEL SCREEN	1		12	265	VB-166	GOVERNOR YOKE	1		2
1		SE-135	FLYWHEEL AIR SHROUD	1		7						
1		SE-135-J	SHROUD with pad for mounting electric starter	8								
3		SE-136-B	CYLINDER SHROUD for engines beginning with Serial No. 1873091	1	1	6						
7		SE-137-B	AIR SHROUD COVER	1	1	6						

Order parts from nearest **SERVICE STATION** shown in directory following parts list.
IMPORTANT: Always give Model, Specification and Serial Numbers as shown on name plate.

PARTS INTERCHANGEABLE ON MODELS TE AND TF

Ref. No.	Part Number	Description	No. Req.	Net Wt.		Ref. No.	Part Number	Description	No. Req.
				Lb	Oz				
266	VE-693	CHOKE CONTROL VE-575-A replaced by VE-693.	1		4	289	PD-78	NUT, 5/16"-18 thread, hexagon steel For oil spray nozzle.	1
267	VE-555-A	GOVERNOR CONTROL ROD to carburetor	1		1	291	PD-109	NUT, 3/8"-24 thread, hexagon brass For manifold to cylinder block studs.	2
268	WD-26-A	MUFFLER	1	2	1	294	PD-147	WING NUT, 1/4"-20 thread	
269	WE-293-1	GEAR COVER SPACER for engines beginning with Serial No. 1964973..... WE-293 Spacer— To and including Serial No. 1964972.	1	1	6	296	PE-3	LOCKWASHER, 1/4" Positive	25
270	WE-302-S1	FUEL TANK ASSEMBLY	1	5	12			2-for fuel tank straps. 3-for mounting oil pump to crankcase. 13-for mounting air shrouding. 4-for mounting governor housing. 4-for gear cover spacer to crankcase. 2-for mounting fuel pump.	
271	WE-302-S2	TANK ASSEMBLY with RM-1211 Suction tube for engines with electric starter (Fuel strainer mounted to tank). NOTE: Fuel tanks were mounted to the tank bracket with steel binder strapping which is not serviceable in the field. When replacing fuel tank, order correct replacement straps.				297	PE-4	LOCKWASHER, 5/16" Positive	21
274	Y-80-S1	MAGNETO, with gear, Fairbanks-Morse No. FMX1-2B7	1		7			2-for carburetor mounting. 3-for flywheel shroud to gear cover. 10-for gear cover and spacer to crankcase. 4-for mounting fuel tank bracket. 2-for mounting air cleaner bracket.	
	Optional	Y-52-S1 and Y-75-S1—replaced by Y-80-S1.				298	PE-5	LOCKWASHER, 3/8" Positive.....	18
	Y-67A-S1	MAGNETO, with gear, Wico XH-2531 Y-55-S1 and Y-67-S1—replaced by Y-67A-S1. NOTE: These engines are equipped with either a 'Fairbanks-Morse' or 'Wico' magneto as shown above. See magneto bulletins in back of manual for service replacement parts list.			6	299	PE-6	LOCKWASHER, 7/16" Positive.....	6
275	YD-6-S1	SPARK PLUG, 18mm, Champion No. D-16 or AC No. CR6 Com.....	2		2	300	PE-46	LOCKWASHER, 5/16" external Everlock 3-for mounting camshaft gear. 1-for oil spray nozzle.	4
276	YD-12	SPARK PLUG SAFETY NIPPLE.....	2		1	301	PE-49	LOCKWASHER, 5/16" countersunk Everlock, for bearing retainer plate—flywheel end	4
277	YL-79	MAGNETO IGNITION CABLE to No. 1 cylinder, 24 3/4" long	1		2	302	PF-18	PIPE PLUG, 1/8" slotted..... 1-for governor housing. 2-for oil holes in crankcase.	3
278	YL-120	MAGNETO IGNITION CABLE to No. 2 cylinder, 21 3/4" long	1		2	303	PF-25	PIPE PLUG, 3/8" slotted..... For gear cover timing hole.	1
STANDARD HARDWARE									
NOTE: The following nuts, washers, capscrews and etc., are of a common hardware variety and can be purchased from local plumbing or hardware stores.									
285	PD-10	NUT, 5/16"-24 thread, hexagon steel.... For connecting rod bolts.	4		1	305	PH-14	PLAIN WASHER, 5/16" copper	2
286	PD-12	NUT, 7/16"-20 thread, hexagon steel For mounting cylinder block to crankcase.	6		1	306	PH-22-A	PLAIN WASHER, 3/8" steel..... For magneto mounting screw—lower hole.	1
287	PD-79	NUT, 3/8"-16 thread, hexagon steel..... For magneto mounting screw, lower hole	1		1	307	PH-77-A	PLAIN WASHER, 5/16" steel..... For mounting cylinder head.	17
288	PD-77	NUT, 1/4"-20 thread, hexagon steel..... For fuel tank straps.	2		1	309	RF-794-A	PIPE NIPPLE, 1/8" x 3/4" long, brass .. For mounting fuel strainer to fuel pump.	1
						310	RF-948	PIPE NIPPLE, 1/8" x 3" long..... For mounting fuel strainer to fuel tank.	1
						311	SA-10	PLUG, 7/8" Expansion	1
						312	SA-52	PLUG, 1/2" Expansion	2
						313	SA-93	PLUG, 5/16" Expansion	1

Order parts from nearest **SERVICE STATION** shown in directory following parts list.
IMPORTANT: Always give Model, Specification and Serial Numbers as shown on name plate.


**PARTS INTERCHANGEABLE ON MODELS TE AND TF
STANDARD HARDWARE**

Ref. No.	Part Number	Description	No. Net Wt.			Ref. No.	Part Number	Description	No. Net Wt.		
			Req	Lb	Oz				Req	Lb	Oz
315	XA-33	SCREW, 1/4"-20 thread x 3/8" long, round head 4-for mounting flywheel screen. 6-for mounting air shroud cover.	10		1	333	XD-19	SCREW, 5/16"-18 thread x 1 1/4" long, (special hardness) hexagon head 8-for gear cover and spacer mounting. 15-for mounting cylinder head.	23		2
316	XA-34	SCREW, 1/4"-20 thread x 1/2" long, round head For air shroud to cylinder block, lower holes.	4		1	334	XD-21	SCREW, 5/16"-18 thread x 1 1/4" long, (special hardness) hexagon head For mounting cylinder head.	2		2
317	XA-36	SCREW, 1/4"-20 thread x 3/4" long, round head For air shroud to cylinder block, upper hole, fan end.	1		1	336	XD-27	SCREW, 3/8"-16 thread x 1" long, hexagon head 4-for main bearing plate—take-off end. 8-for mounting engine base.	12		2
318	XA-38	SCREW, 1/4"-20 thread x 1" long, round head For air shroud to cylinder block, upper hole, take-off end.	1		1	337	XD-33	SCREW, 3/8"-16 thread x 2 1/4" long, hexagon head For mounting magne	2		2
319	XA-52	SCREW, 1/4"-20 thread x 1 1/2" long, round head For fuel tank straps.	2		1	338	XD-34	SCREW, 3/8"-16 thread : 2 1/4" long, hexagon head For mounting engine base—from bottom. XD-113 Screw, 2 3/4" long—replaced by XD-34.	2		2
320	XA-67	SCREW, No. 4 x 1/4" long, self-tapping sheet metal For mounting name and instruction plate.	4		1	340	XH-1	TAPER PIN, No. 0 x 3/4" long For governor yoke.	1		1
322	XC-17	SCREW, 5/16"-18 thread x 3/4" long, flat head For bearing retainer plate—flywheel end	4		1	341	XI-32	COTTER PIN, 3/64" x 3/8" long For governor control rod.	1		1
324	XD-4	SCREW, 1/4"-20 thread x 1/2" long, hexagon head For mounting spacer plate to crankcase	4		1	344	XK-1	PIPE PLUG, 1/8" square head For tap in inlet manifold.	1		1
325	XD-5	SCREW, 1/4"-20 thread x 5/8" long, hexagon head For mounting oil pump.	3		1	345	XK-3	PIPE PLUG, 3/8" square head For oil drain.	2		1
326	XD-6	SCREW, 1/4"-20 thread x 3/4" long, hexagon head 2-for mounting governor housing—lower holes. 2-for mounting fuel pump.	4		1	346	XK-121	PIPE PLUG, 1/8" Allen socket head For oil header tube—from face of crankcase.	1		1
328	XD-11	SCREW, 1/4"-20 thread x 2" long, hexagon head For mounting governor housing—upper holes.	2		1						
329	XD-13	SCREW, 5/16"-18 thread x 1/2" long, hexagon head 3-for mounting air shroud to gear cover. 4-for mounting fuel tank bracket. PC-396 Studs for mounting fuel tank—replaced by XD-13.	7		1						
330	XD-14	SCREW, 5/16"-18 thread x 5/8" long, hexagon head For gear cover to spacer plate—magneto side and upper hole.	2		1						
331	XD-16	SCREW, 5/16"-18 thread x 7/8" long, hexagon head For mounting carburetor.	2		1						
332	XD-17	SCREW, 5/16"-18 thread x 1" long, hexagon head 3-for mounting camshaft gear. 2-for mounting air cleaner bracket.	5		1						

Order parts from nearest **SERVICE STATION** shown in directory following parts list.

IMPORTANT: Always give Model, Specification and Serial Numbers as shown on name plate.

TE AND TF POWER UNIT WITH FUEL TANK AT TAKE-OFF END
OR UNDERSLUNG FUEL TANK




ENGINE HOUSE AND FUEL TANK GROUP

Parts are identified by reference number. See parts list for correct part number.

151298C

TT-66 VARIABLE SPEED GOVERNOR CONTROL ASSEMBLY FOR TE AND TF ENGINES




152522C

REF. NO.	PART NUMBER	DESCRIPTION	NO. REQ.	NET WEIGHT	
				LB	OZ
	TT-66	GOVERNOR CONTROL ASSEMBLY - Complete.....	1	1	
475	PD-173-A	ADJUSTING SCREW LOCKNUT (Standard engine part).....	1		1
476	PI-115-E	ADJUSTING SCREW.....	1		2
477	PM-111-1	SPRING for adjusting screw.....	1		1
478	TC-368-A	SWIVEL PIN for adjusting screw.....	1		1
479	VB-134-C	LEVER.....	1		4
480	VE-527-W	CONTROL..... VE-527 with 3/16" shaft, replaced by VE-527-W with 1/4" shaft. Also order VE-542-B Stop Block.	1		6
481	VE-542-B	STOP COLLAR for control..... VE-542 for VE-527 Control with 3/16" shaft. VE-542-B for VE-527-W control with 1/4" shaft.	1		1
STANDARD HARDWARE					
484	PH-77	PLAIN WASHER, 5/16" I.D. x 5/8" O.D. x 1/16" thick steel..... For lever mounting.	1		1
485	XA-62	SCREW, No. 8-32 thread x 1/4" long, round head..... For cotter pin in lever.	1		1
486	XE-61	SET SCREW, No. 10-32 thread x 3/16" long, headless..... For stop collar.	1		1
487	XI-1	COTTER PIN, 1/16" x 1/2" long..... 1-for lever pin. 1-for adjusting screw pin. 1-for chain at control.	3		1
488	XI-11	COTTER PIN, 3/32" x 1/4" long..... For chain at lever.	1		1
489		No. 1/0 GALVANIZED SAFETY CHAIN, 9" long..... For control to lever.	1 pc		1

Order parts from nearest **SERVICE STATION** shown in directory following parts list.

IMPORTANT: Always give Model, Specification and Serial Numbers as shown on name plate.

ELECTRIC STARTER, GENERATOR AND DISTRIBUTOR IGNITION FOR TE AND TF ENGINES



Ref. No.	Part Number	Description	No. Req.	Net Wt.		Ref. No.	Part Number	Description	No. Req.	Net Wt.	
				Lb	Oz					Lb	Oz
500	GD-97-A	DRIVE GEAR for generator	1		7	512	YA-19	ELECTRIC STARTER (6 volt), Auto-Lite No. MZ-4184	1		17
501	PC-110	STUD for mounting generator, lower hole	1		1			YA-10 Auto-Lite No. MZ-4118 and MZ-4175 replaced by YA-19.			
502	PG-516-A	BRACKET for starter support..... PG-516—replaced by PG-516-A.	1		4			NOTE: See Electric Auto-Lite illustration and parts list for starter service parts.			
503	PG-556	BRACKET for mounting coil.....	1		4	513	YB-26-A	GENERATOR (6 volt) Auto-Lite No. GAS-4305	1		15
504	QD-616	GASKET for mounting generator	1		1			YB-26-A replaced YB-26 Auto-Lite No. GAS-4302.			
505	R-123-8	OIL FILLER ASSEMBLY	1		6			NOTE: See Electric Auto-Lite illustration and parts list for generator service parts.			
		Consisting of: 1 LJ-310 Pipe				514	YC-9-B	IGNITION SWITCH.....	1		2
506	RJ-148	OIL LEVEL GAUGE.....	1		3			YC-9 Switch replaced by YC-9-B.			
508	RP-911	DRIP TUBE ASSEMBLY for carburetor..	1		2	515	YC-10	STARTING SWITCH	1		4
		Consisting of: 1 RF-270-4 Elbow				517	YD-165	JUMPER STRIP for regulator	1		1
		1 RF-808 Nut				518	YE-2	AMMETER	1		6
		1 RF-731 Tube				519	YF-6-E	DISTRIBUTOR, Auto-Lite IGW-4199A ..	1	2	6
509	SD-109	TAG for ignition switch.....	1		1			YF-6-E replaced YF-6-D Auto-Lite No. IGW-4168-B.			
511	VE-566	CONTROL PANEL	1		10			NOTE: See Electric Auto-Lite illustration and parts list for distributor service parts.			

Order parts from nearest **SERVICE STATION** shown in directory following parts list.
IMPORTANT: Always give Model, Specification and Serial numbers as shown on name plate.

ELECTRIC STARTER, GENERATOR AND DISTRIBUTOR IGNITION FOR TE AND TF ENGINES

Ref. No.	Part Number	Description	No.			Ref. No.	Part Number	Description	No.		
			Req	Lb	Oz				Req	Lb	Oz
520	YF-11	IGNITION COIL (6 volt) Auto-Lite No. CR-6005 YF-4-A Coil, Auto-Lite No. IG-6001—replaced by YF-11 but PG-556 Bracket must also be ordered.	1	1	12	545	XA-79	SCREW, No. 14 x 1/2" long, Type A, self-tapping sheet metal screw For mounting control panel.	2		1
522	YL-105	SPARK PLUG CABLE, 22" long, distributor to No. 2 cylinder.....	1		2	546	XD-6	SCREW, 1/4"-20 thread x 3/4" long, hexagon head..... For mounting starter bracket.	2		1
523	YL-164	SPARK PLUG CABLE, 25" long, distributor to No. 1 cylinder.....	1		2	548	XD-16	SCREW, 5/16"-18 thread x 7/8" long, hexagon head..... For mounting coil bracket.	1		1
524	YL-165	IGNITION CABLE, 27" long, distributor to coil.....	1		2	549	XD-33	SCREW, 3/8"-16 thread x 2 1/2" long, hexagon head..... For mounting generator, top hole.	1		2
526	YL-151	IGNITION WIRE ASSEMBLY, 14" long, ignition switch to coil.....	1	1		550	XK-105	PIPE ELBOW, 1/2" x 45°..... For oil filler mounting.	1		3
527	YL-179	IGNITION WIRE ASSEMBLY, 3" long, ammeter to ignition switch.....	1	1							
528	YL-181	IGNITION WIRE ASSEMBLY, 20" long, coil to distributor.....	1	1							
529	YL-184	IGNITION WIRE ASSEMBLY, 3" long, starting switch to ammeter.....	1	1							
530	YL-185	IGNITION WIRE ASSEMBLY, 15" long, ammeter to regulator.....	1	1							
531	YL-186	STARTER CABLE ASSEMBLY, 19" long	1		4						
STANDARD HARDWARE											
533	LJ-331	PIPE NIPPLE, 1/2" x 3/4" long For oil filler.	1		4						
534	PB-24	SCREW, 3/8"-24 thread x 1-1/8" long, hexagon head..... For mounting starter.	3		2						
535	PD-11	NUT, 3/8"-24 thread, hexagon steel..... For generator stud, lower hole.	1	1							
536	PD-77	NUT, 1/4"-20 thread, hexagon steel..... For starter switch mounting.	2	1							
538	PE-3	LOCKWASHER, 1/4" Positive..... For starter switch mounting.	2	1							
539	PE-4	LOCKWASHER, 5/16" Positive..... For mounting coil bracket.	1	1							
540	PE-5	LOCKWASHER, 3/8" Positive..... 3-for mounting starter. 2-for mounting generator.	5	1							
542	PH-30	WASHER, 1/4" plain copper..... For mounting starter bracket.	2	1							
544	XA-34	SCREW, 1/4"-20 thread x 1/2" long, round head..... For starter switch mounting.	2	1							


Order parts from nearest **SERVICE STATION** shown in directory following parts list.

IMPORTANT: Always give Model, Specification and Serial Numbers as shown on name plate.

ELECTRIC AUTO-LITE No. MZ-4184 STARTING MOTOR PARTS LIST

WISCONSIN MOTOR PART NUMBER YA-19

NOTE: MZ-4184 (YA-19) is a completely dust sealed starting motor, which replaces MZ-4175 (YA-10), and is interchangeable as a complete unit.




209102

Ref No	Auto-Lite Part Number	Description	No Req
1	MZ-2001M	FRAME and FIELD ASSEMBLY	1
2	MAB-31A	Consisting of:	
3	MU-14	INSULATING WASHER for terminal stud.....	1
4	MU-28	TERMINAL STUD.....	1
5	MU-31	INSULATING BUSHING for terminal stud.....	1
6	MU-37	PLAIN WASHER, 5/16", for terminal stud.....	1
7	MU-39A	INSULATING WASHER for terminal stud.....	1
8	MZ-12	INSULATED BRUSH.....	2
9	MZ-30A	INSULATION for field coils.....	1
10	MZ-38A	SCREW for pole shoe.....	4
11	MZ-74	EQUALIZER (not illustrated).....	1
12	12X-1014	LOCKWASHER, 5/16", for terminal stud.....	2
13	8X-1376	NUT for terminal stud, 5/16"-24 thread, hex.....	2
14	MZ-3005S	FIELD COIL ASSEMBLY.....	1
15	MZ-32	Consisting of:	
16	MZ-1007	CONNECTOR for field coil.....	2
17	MZ-1008	FIELD COIL, U.L.....	1
18	MZ-1009	FIELD COIL, L.R.....	1
19	MZ-1010	FIELD COIL, L.L.....	1
20	MZ-2002B	COMMUTATOR END HEAD ASSEMBLY	1
21	MAD-110	Includes:	
22	MZ-19	FELT (not illustrated).....	1
23	MZ-1034S	BRUSH SPRING.....	4
24	12X-196	GROUNDING BRUSH.....	2
25	8X-902	LOCKWASHER for head screw, No. 10.....	4
26	MZ-2366	SCREW for head mounting.....	4
27	MU-54	No. 10-32 thread x 3/8" long, fillister head.	
28	MZ-365	ARMATURE ASSEMBLY.....	1
29	MZ-357	THRUST WASHER for Armature, C.E.....	1
		THRUST WASHER for Armature.....	1
		THRUST WASHER for Armature, Int.....	2

Ref No	Auto-Lite Part Number	Description	No Req
30	X-261	KEY for mounting Bendix, No. 6 Woodruff.....	1
31	EBB-45A	BENDIX DRIVE ASSEMBLY.....	1
32	EB-108A	Consisting of:	
33	EB-7819SA	LOCKWASHER.....	2
34	EB-8503A	COMPRESSION SLEEVE (not illustrated).....	1
35	EB-8506A	DRIVE HEAD.....	1
36	EB-8507A	SCREW for spring head.....	1
37	EBA-405A	SCREW for spring shaft.....	1
38	EBB-4511A	DRIVE SPRING.....	1
		SHAFT and PINION.....	1
39	MZ-1360	BEARING PLATE ASSEMBLY, intermediate.....	1
40	MZ-359	GASKET for bearing plate.....	1
41	8X-63	SCREW for mounting bearing plate.....	4
		No. 8-32 thread x 3/8" long, flat head.	
42	PS-1330	PINION HOUSING ASSEMBLY.....	1
43	MZ-358	Includes:	
44	MZ-364	BEARING CAP.....	1
45	XA-832	BRONZE BEARING.....	1
		OIL SEAL.....	1
46	MZ-52	SCREW for pinion housing mounting.....	4
		No. 10-32 thread x 31/32" long, hexagon head.	
47	12X-196	LOCKWASHER for housing screw, No. 10.....	4
48	MZ-1024U	COVER BAND.....	1
49	8X-714	SCREW for cover band.....	1
		No. 10-32 thread x 1-1/2" long, round head.	
50	8X-794	NUT for cover band.....	2
		No. 10-32 thread, square.	

* BRUSH SET for SERVICE, MZ-20124S

ELECTRIC AUTO-LITE †MZ-4175 STARTING MOTOR PARTS LIST
WISCONSIN MOTOR PART NUMBER YA-10




†MZ-4118 replaced by MZ-4175 with dust proof Bendix. Individual parts changes noted below.

179859C

Ref No	Auto-Lite Part Number	Description	No Req	Ref No	Auto-Lite Part Number	Description	No Req
1	MZ-2001M	FRAME and FIELD ASSEMBLY MZ-2001 repl. by MZ-2001M: Interchangeable. Consisting of:	1	28	MU-54	THRUST WASHER for armature	2
2	MAB-31-A	INSULATING WASHER for terminal stud.....	1	29	X-261	KEY for mounting Bendix, No. 6 Woodruff	1
3	MU-14	TERMINAL.....	1	30	EBB-36A	BENDIX DRIVE ASSEMBLY EBA-36A repl. by EBB-36A: Interchangeable. Consisting of:	1
4	MU-28	TERMINAL STUD.....	1	31	EB-108A	LOCKWASHERS	2
5	MU-31	INSULATING BUSHING for terminal stud.....	1	32	EB-78195A	COMPRESSION SLEEVE (not illustrated)	1
6	MU-37	PLAIN WASHER, 5/16", for terminal stud.....	1	33	EB-8503A	DRIVING HEAD	1
7	MU-39A	INSULATING WASHER for terminal stud.....	1	34	EB-8506A	SCREW for spring head	1
8	MZ-12 *	INSULATED BRUSH	2	35	EB-8507A	SCREW for spring shaft	1
9	MZ-30A	INSULATION for field coils	1	36	EB-8734A	TAKE-UP RING (not illustrated)	1
10	MZ-38A	SCREW for pole shoe	4	37	EBA-405A	DRIVE SPRING	1
11	MZ-74	EQUALIZER (not illustrated).....	1	38	EBB-3611A	SHAFT and PINION	1
12	12X-1014	LOCKWASHER, 5/16", for terminal stud.....	2			EBA-3611A repl. by EBB-3611A: Interchangeable.	
13	8X-1376	NUT for terminal stud, 5/16"-24 thread, hex. ...	2	39	MAB-2040	BEARING and PLATE ASSEMBLY	1
14	MZ-30055	FIELD COIL ASSEMBLY	1			Includes:	
		Consisting of:		40	MG-77A	BRONZE BEARING.....	1
15	MZ-32	CONNECTOR for field coil.....	2	41	MZ-52	SCREW for pinion housing mounting	4
16	MZ-1007	FIELD COIL, U.L.....	1			No. 10-32 thread x 31/32" long.	
17	MZ-1008	FIELD COIL, L.R.....	1	42	12X-196	LOCKWASHER for housing screw, No. 10	4
18	MZ-1009	FIELD COIL, L.L.....	1	43	PS-1214	PINION HOUSING ASSEMBLY	1
19	MZ-1010	FIELD COIL, U.R.....	1			Includes:	
20	MZ-2002B	COMMUTATOR END HEAD ASSEMBLY	1	44	MAB-88	DOWEL PIN (not illustrated)	1
		Includes:		45	MP-41A	BRONZE BEARING (not illustrated)	1
21	MAD-110	FELT (not illustrated)	1	46	MZ-1024U	COVER BAND	1
22	MZ-19	BRUSH SPRING	4			MZ-1024 repl. by MZ-1024U: Interchangeable.	
23	MZ-1034S *	GROUNDING BRUSH.....	2	47	8X-714	SCREW for cover band	1
24	12X-196	LOCKWASHER for head screw, No. 10.....	4			No. 10-32 thread x 1 1/2" long, round head.	
25	8X-902	SCREW for head mounting	4	48	8X-794	NUT for cover band.....	1
26	MZ-2089	ARMATURE ASSEMBLY	1			No. 10-32 thread, square.	
		Includes:				* BRUSH SET for SERVICE, MZ-2012AS	
27	MZ-51	THRUST SPACER (not illustrated)	1				

ELECTRIC AUTO-LITE No. GAS-4302, WIS. MOTOR No. YB-26 GENERATOR
 ELECTRIC AUTO-LITE No. GAS-4305, WIS. MOTOR No. YB-26-A GENERATOR



Ref. No. 10 COMMUTATOR END HEAD ASSEMBLY

Parts are identified by reference number. See parts list for correct part number.

YB-26 (GAS-4302) GENERATOR – WITH REGULATOR – PARTS LIST
YB-26-A (GAS-4305) GENERATOR – WITH CUT-OUT RELAY – PARTS LIST


Ref No	Auto-Lite Part Number	Description	No Req	Ref No	Auto-Lite Part Number	Description	No Req
1	GAS-2167 GAS-2364	FRAME and FIELD ASSEMBLY (YB-26) FRAME and FIELD ASSEMBLY (YB-26-A)	1	48	GAL-98	DISTRIBUTOR MOUNTING HOUSING	1
2	GAS-44	Consisting of: INSULATION for field coil connection	1	49	GE-58	DISTRIBUTOR DRIVER GEAR	1
3	GAS-45	HOLDER for field coil	4	50	SW-213	PIN for driver gear	1
4	GAS-86	LEAD WIRE with terminal	1	51	GAG-58	CLAMP for distributor housing	1
5	MN-21	DOWEL PIN	2	52	8X-53	SCREW for clamp	1
6	MZ-38A	POLE SHOE SCREW	2			No. 8-32 thread x 5/8" long, round head.	
7	X-755	TERMINAL	2	53	8X-141	NUT for clamp screw, No. 8-32 thread, hex. ..	1
8	GAS-121 GT-7	INSULATING BUSHING (YB-26)	1	54	X-382	GREASE CUP	1
9	GAS-2005D GAS-2005A	INSULATING BUSHING (YB-26-A)	1	55	GW-19-A	COVER for distributor housing	1
10	GAS-2132AS	FIELD COIL ASSEMBLY complete (YB-26).. FIELD COIL ASSEMBLY complete (YB-26A)	1	56	8X-900	SCREW for distributor housing mounting	3
11	GAS-51	COMMUTATOR END HEAD ASSEMBLY	1			No. 10-32 thread x 7/8" long, fillister head.	
12	GAS-281	Consisting of: SPRING RETAINER for 3rd brush plate	2	57	GAS-20A	THRU BOLT for end heads mounting	2
13	IG-515A	FELT WICK	1	58	12X-196	LOCKWASHER, No. 10 Positive	5
14	X-1275	SPRING for felt wick	1			2-for thru bolts. 3-for distributor housing.	
15	X-1573	WASHER for felt wick	1	59	GAS-1024JS	BAND for cover	1
16	GAS-11325	OILER	1	60	X-714	SCREW for band cover	1
17	GAS-49	HEAD with GAS-49 bearing	1	61	8X-794	NUT for band cover screw	1
18	GAS-2021RA	BRONZE BEARING	1			No. 10-32 thread, square.	
19	GAL-31	MAIN BRUSH PLATE ASSEMBLY	1	62	CB-4014	CUT-OUT RELAY ASSEMBLY (YB-26-A)	1
20	GAS-12 *	Consisting of: GROUND WIRE with terminals	1	63	GAS-87	SPACER for mounting relay (YB-26-A)	2
21	GAS-15	MAIN BRUSH	2	64	TC-4329C	TWO CHARGE REGULATOR (YB-26)	1
22	GAS-17	BRUSH HOLDER	2	65	X-842	FUSE for regulator, 5 Amp (YB-26)	1
23	GAS-18	SPRING for grounded brush	1	66	GAS-168	SPACER for mounting regulator (YB-26)	2
24	GAS-1021R	SPRING for insulated brush	1	67	8X-311	SCREW for mounting regulator or relay	4
25	8X-122	MAIN BRUSH PLATE	1			No. 10-32 thread x 3/8" long, round head.	
26	12X-195	SCREW for grounded brush	1	68	12X-196	LOCKWASHER for mounting regulator or relay, No. 10	4
27	8X-1496	No. 8-32 thread x 1/2" long, fillister head. LOCKWASHER for brush screw, No. 8	2	69	TC-51E	CARBON RESISTOR for regulator (YB-26)	1
28	GAS-2126A	SCREW for insulated brush	1	70	TC-1050	FUSE HOLDER (YB-26)	1
29	GAS-13 *	No. 8-32 thread x 7/16" long, binding head. 3rd BRUSH PLATE ASSEMBLY	1	71	TC-48	FUSE INSULATOR (YB-26)	1
30	GAS-15	Consisting of: THIRD BRUSH	1				
31	GAS-17	BRUSH HOLDER	1				
32	GAS-1126	BRUSH SPRING	1				
33	8X-878	3rd BRUSH PLATE	1				
34	12X-195	SCREW for third brush	1				
35	8X-55	No. 8-32 thread x 7/16" long, fillister head. LOCKWASHER for 3rd brush screw, No. 8 ..	1				
36	12X-195	SCREW for plate mounting	3				
37	GAS-1232AS	No. 8-32 thread x 3/8" long, round head. LOCKWASHER for plate mounting, No. 8	1				
38	GAS-232AS	DRIVE END HEAD ASSEMBLY	1				
39	X-3003	Consisting of: HEAD	1				
40	GAS-177	BALL BEARING, shielded, S.A.E. No. 204 ..	1				
41	8X-63	BEARING RETAINER	1				
42	GAS-1176	SCREW for retainer	3				
43	X-835	No. 8-32 thread x 3/8" long, flat head.					
44	GK-174A	OIL THROWER	1				
45	X-404	NUT for armature shaft, 1/2"-20 thread, slotted	1				
46	X-263	WASHER for armature shaft nut, 1/2" plain	1				
47	GAS-2175	COTTER PIN for nut, 3/32" x 1" long	1				
		KEY for drive gear, No. 8 Woodruff	1				
		ARMATURE	1				

* BRUSH SET for SERVICE, GAS-2012.

YF-6-F AUTO-LITE IGW-4199B DISTRIBUTOR
 YF-6-E AUTO-LITE IGW-4199A DISTRIBUTOR
 YF-6-D AUTO-LITE IGW-4168B DISTRIBUTOR

PARTS LIST


(YF-6-E Replaced YF-6-D, Interchangeable)



179856C

Ref No	Auto-Lite Part Number	Description	No Req	Ref No	Auto-Lite Part Number	Description	No Req
1	CB-140	INSULATING BUSHING for terminal stud	1	21	IGW-30285	BREAKER CONTACT SET	1
2	GK-36	FOLLOWER GEAR	1	22	IGW-3143LA	SHAFT and GOVERNOR ASSEMBLY for YF-6D	1
3	IB-23	LOCKNUT for contact screw	1		IGW-3143LB	& YF-6E	1
4	IG-90	THRUST WASHER for drive shaft, lower	1			For YF-6F	1
5	IG-495	FELT WICK for cam sleeve	1	23	IGB-3275	Consisting of: SPRING SET for governor weights	1
6	IG-2860A-3	ADVANCE ARM	1	24	IGW-37	CAM RETAINING SPRING	1
7	IGB-21	INSULATION for terminal stud	1	25	IGW-92	CAM SPACER	1
8	IGB-22	INSULATING WASHER for terminal stud	1	26	IGW-1063L	GOVERNOR WEIGHT	2
9	IGB-1065-C	DISTRIBUTOR CAP for YF-6E & YF-6F	1	27	IGW-2100LAB	CAM and STOP PLATE for YF-6D & YF-6E	1
	IGB-1065	For YF-6-D Auto-Lite IGW-4168-B	1		IGW-2100LAF	For YF-6F	1
10	IGB-1007	CLAMP SPRING and HINGE for cap	2	28	IGW-2143L	DRIVE SHAFT	1
11	IGB-1010	BREAKER PLATE	1	29	SW-213	RIVET for gear	1
12	IGB-1025E	CONDENSER	1	30	8X-59	SCREW for condenser mounting	1
13	IGB-1002	ROTOR	1			No. 8-32 thread x 3/16" long, round head.	
14	IGS-104	THRUST WASHER for drive shaft, upper	1	31	X-1276	WASHER for condenser mounting	1
15	IGW-38	INSULATING WASHER for terminal stud	1			Shakeproof No. 8, External.	
16	IGW-39	TERMINAL STUD	1	32	8X-173	NUT for terminal stud	2
17	IGW-54	WASHER for terminal stud	1			No. 10-32 thread, hexagon.	
19	IGW-2163A	BASE ASSEMBLY for YF-6E & YF-6F	1	33	12X-196	LOCKWASHER for terminal stud, No. 10	2
		Includes:		34	8X-183A	WASHER for terminal stud, No. 10 plain	1
		IG-579A Bronze Bearings (not illustrated)...	2	35	12X-195	LOCKWASHER for breaker plate, No. 8	3
		VRP-26 Felt (not illustrated).....	1	36	8X-304	SCREW for breaker plate mounting	3
		XA-880 Felt Retainer (not illustrated).....	1			No. 8-32 thread x 5/16" long, round head.	
	IGW-2163	For YF-6-D Auto-Lite IGW-4168B.....	1	37	X-1270	WASHER for terminal stud	1
		Includes:				Shakeproof No. 10.	
		IG-579A Bronze Bearings (not illustrated)...	2	38	X-1601	GREASE CUP	1
				39	IG-816	THRUST WASHER for advance arm	1
						For YF-6D Auto-Lite IGW-4168B only.	

WW-74-A CLUTCH AND POWER TAKE-OFF ASSEMBLY FOR TE AND TF ENGINES



NOTE: Engines equipped with a clutch and power take-off assembly, require a special main bearing plate assembly, crankshaft and crankcase as follows: 152525C

- BG-224-B-52 MAIN BEARING PLATE ASSEMBLY** (not illustrated) consisting of:
 1 BG-224-B Bearing Plate 1 ME-130-2 Bearing Cup 1 PH-364 Oil Seal
- CA-62-2-S1 CRANKSHAFT ASSEMBLY** (not illustrated) consisting of:
 1 CA-62-2 Crankshaft 1 ME-71 Bearing 1 PL-53 Key
 1 GA-36A-1 Gear 1 ME-130 Bearing

THE PART NUMBER OF THE CRANKCASE IS STAMPED ON THE FACE OF THE CASE ABOVE THE BEARING PLATE AT THE TAKE-OFF END

Ref. No.	Part Number	Description	No.		Net Wt.		Ref. No.	Part Number	Description	No.		Net Wt.	
			Req		Lb	Oz				Req		Lb	Oz
	WW-74-A	CLUTCH and POWER TAKE-OFF ASSEMBLY. Consisting of.....	1		30		613	SD-132	INSTRUCTION PLATE	1			1
									For clutch adjustment.				
600	BG-156	RETAINER PLATE for bearing.....	1		8		614	VB-55-1	SHIFTER LEVER	1		2	
601	BG-230-2	CLUTCH HOUSING	1		6		615	VB-64-A	SHIFTER YOKE	1	1	4	
602	BH-115	COVER for inspection opening	1		8		616	WA-61	SHAFT for shifter yoke	1		1	
603	LO-44	BREATHER ASSEMBLY	1		1		617	WA-94	TAKE-OFF SHAFT.....	1		3	
604	ME-79-A	BEARING for take-off shaft, N. D. 7507..	1		10		618	WC-280-A	CLUTCH ASSEMBLY	1		12	
605	ME-131-A	BALL BEARING for clutch shaft pilot..	1		6				Rockford Drilling Model 4 1/2 L.O.C.				
606	PC-392	STUD for mounting clutch housing	4		2				No. CLA-1721-1.				
607	PH-234-A	OIL SEAL for shifter lever shaft.....	1		2		619	XD-14-2	SET SCREW for clutch drive hub.....	1		1	
608	PH-280	OIL SEAL for take-off shaft.....	1		3								
609	PK-56	RETAINING RING for bearing	2		1				STANDARD HARDWARE				
610	QD-551	GASKET for inspection cover	1		1		622	PD-12	NUT, 7/16"-20 thread, hexagon steel....	4		1	
611	QD-650-1	GASKET for housing mounting	1		1				For clutch housing studs.				
612	SD-79	TAG for oil instructions	1		1		623	PE-6	LOCKWASHER, 7/16" Positive	4		1	
									For clutch housing stud nuts.				


Order parts from nearest **SERVICE STATION** shown in directory following parts list.
IMPORTANT: Always give Model, Specification and Serial Numbers as shown on name plate.

**WW-74-A CLUTCH AND POWER TAKE-OFF ASSEMBLY
FOR TE AND TF ENGINES**

Ref. No.	Part Number	Description	No. Req.	Net Wt.		Ref. No.	Part Number	Description	No. Req.	Net Wt.	
				Lb	Oz					Lb	Oz
624	PE-46	LOCKWASHER, 5/16" External Everlock For drive hub set screw.	1		1	630	XD-8	SCREW, 1/4"-20 thread x 1 1/4" long, hex- agon head..... For bearing retainer plate.	4		1
625	PH-30	WASHER, 1/4" I.D. x 7/16" O.D. x 1/16" thick, copper..... 4-for inspection opening cover. 4-for bearing retainer plate.	8		1	631	XD-30	SCREW, 3/8"-16 thread x 1 1/2" long, hex- agon head..... For shifter lever.	1		1
626	PL-47	KEY, No. 18 Woodruff..... For clutch drive hub.	1		1	632	XH-26	TAPER PIN, No. 4 x 1-3/8" long..... For shifter lever.	1		1
627	SA-58	PLUG, 1-3/8" Expansion..... For shifter shaft hole.	1		1	633	XK-1	PIPE PLUG, 1/8" square head..... For oil level.	2		1
628	XA-100	SCREW, No. 4 x 1/4" round head, metallic drive. For clutch adjustment plate..... XA-68, No. 2 x 1/4" Screw—repl. by XA-100.	2		1	634	XK-2	PIPE PLUG, 1/4" square head..... For oil drain.	1		1
629	XD-5	SCREW, 1/4"-20 thread x 5/8" long, hex- agon head..... For inspection opening cover.	4		1	635	XK-77	STREET ELL, 1/8" x 45°..... For breather mounting.	1		1

Order parts from nearest **SERVICE STATION** shown in directory following parts list.
IMPORTANT: Always give Model, Specification and Serial Numbers as shown on name plate.

ROCKFORD No. CLA-1721-1 CLUTCH ASSEMBLY
WISCONSIN MOTOR PART No. WC-280-A




206584C-A

Ref. No.	Rockford Part Number	Description	No Req	Ref. No.	Rockford Part Number	Description	No Req
1	CL-7248	CLUTCH HOUSING	1	17	CL-5092	COTTER PIN for link pins, 1/16" x 3/8" long.	6
2	CL-7012	ADJUSTMENT LOCK.....	1	18	UCL-5229-L	RELEASE SLEEVE ASSEMBLY	1
3	CL-3917-1	SCREW for adjustment lock, 1/4"-20 thread x 3/8" long, fillister head	1	19		Consisting of: CL-5229 Release sleeve	1
4	CL-3468	WASHER for adjustment lock, 1/4" Shakeproof	1	20		UCL-7-4966 Release bearing assembly.....	1
5	UCL-5230	DRIVE MEMBER ASSEMBLY.....	1		*	Consisting of: Release bearing (2 halves)	
6		Consisting of: Splined center and plate assembly.....	1	21		CL-3335-1 Hexagon head screw, 5/16"-24 thread x 1-3/4" long	2
7		CL-4096-1 Facing (Raybestos No. 500B)	2	22		CL-7356 Elastic stop nut, 5/16"-24 thread	2
		CL-1011 Brass rivet.....	6	23	CL-4964	ADJUSTING RING	1
8	UCL-1-5228-A	PRESSURE PLATE and LEVER ASSEMBLY..	1	24	CL-5087	SPRING	3
9		Consisting of: UCL-5228 Pressure plate assembly	1	25	CL-5318	CLAMP SCREW, 3/8"-24 thread x 2-1/2" long, hexagon head.....	2
10		CL-5543 Lever	6	26	CL-5319	NUT, 3/8"-24 thread, light hexagon	2
11		CL-5156 Lever pin	3	27	CL-5211	SCREW LOCK.....	2
12		LM-408 Roller	3	28	PT-353	LOCKWASHER, 3/8" Positive	2
13		CL-4775 Roller and CL-4971 Pin replaced by LM-408.	3			(*) Not serviced separately from sub-assembly it is included in.	
14	CL-4776	CONNECTING LINK	6				
15	CL-5153	LINK PIN (long).....	3				
16	CL-5152	LINK PIN (short)	3				





Order parts from nearest **SERVICE STATION** shown in directory following parts list.
IMPORTANT: Always give Model, Specification and Serial Numbers as shown on name plate.

WW-77-A ETC. REDUCTION GEAR ASSEMBLIES
FOR TE AND TF ENGINES



Parts are identified by reference number. See parts list for correct part number.

WW-77-A ETC. REDUCTION GEAR ASSEMBLIES FOR TE AND TF ENGINES

Position of Take-off Shaft Viewing From Cranking End of Engine	Assembly Number	Reduction Ratio	Rotation of Take-off Shaft	Ref. No. 700 Driver Gear Part No.	Ref. No. 701 Driven Gear Part No.	Ref. No. 702 Chain Part No.	Ref. No. 703 Housing Part No.	Ref. No. 704 Housing Cover Part No.
 TAKE-OFF SHAFT BELOW	WW-77-A	2.07 to 1	Counter Engine-Wise	GG-66-3	GG-67-1	BG-231-4	BH-119
	WW-77A-1	3.00 to 1	Counter Engine-Wise	GG-79-1	GG-77-1	BG-231-4	BH-119
	WW-77A-2	3.84 to 1	Counter Engine-Wise	GG-80-1	GG-69-1	BG-231-4	BH-119
	WW-77A-3	2.00 to 1	Engine-Wise	GG-81	GG-71	GJ-8	BG-231-4	BH-119
	WW-77A-4	2.67 to 1	Engine-Wise	GG-82	GG-71	GJ-9	BG-231-4	BH-119
WW-77A-5	3.79 to 1	Engine-Wise	Engine-Wise	GG-83	GG-73	GJ-10	BG-231-4	BH-119
 TAKE-OFF SHAFT ON LEFT HAND SIDE as Viewed from the Cranking End	WW-77A-6	2.07 to 1	Counter Engine-Wise	GG-66-3	GG-67-1	BG-231-5	BH-119-1
	WW-77A-7	3.00 to 1	Counter Engine-Wise	GG-79-1	GG-77-1	BG-231-5	BH-119-1
	WW-77A-8	3.84 to 1	Counter Engine-Wise	GG-80-1	GG-69-1	BG-231-5	BH-119-1
	WW-77A-9	2.00 to 1	Engine-Wise	GG-81	GG-71	GJ-8	BG-231-5	BH-119-1
	WW-77A-10	2.67 to 1	Engine-Wise	GG-82	GG-71	GJ-9	BG-231-5	BH-119-1
WW-77A-11	3.79 to 1	Engine-Wise	Engine-Wise	GG-83	GG-73	GJ-10	BG-231-5	BH-119-1
 TAKE-OFF SHAFT ON RIGHT HAND SIDE as Viewed from the Cranking End	WW-77A-12	2.07 to 1	Counter Engine-Wise	GG-66-3	GG-67-1	BG-231-6	BH-119-2
	WW-77A-13	3.00 to 1	Counter Engine-Wise	GG-79-1	GG-77-1	BG-231-6	BH-119-2
	WW-77A-14	3.84 to 1	Counter Engine-Wise	GG-80-1	GG-69-1	BG-231-6	BH-119-2
	WW-77A-15	2.00 to 1	Engine-Wise	GG-81	GG-71	GJ-8	BG-231-6	BH-119-2
	WW-77A-16	2.67 to 1	Engine-Wise	GG-82	GG-71	GJ-9	BG-231-6	BH-119-2
WW-77A-17	3.79 to 1	Engine-Wise	Engine-Wise	GG-83	GG-73	GJ-10	BG-231-6	BH-119-2
 TAKE-OFF SHAFT ON TOP	WW-77A-18	2.07 to 1	Counter Engine-Wise	GG-66-3	GG-67-1	BG-231-7	BH-119-6
	WW-77A-19	3.00 to 1	Counter Engine-Wise	GG-79-1	GG-77-1	BG-231-7	BH-119-6
	WW-77A-20	3.84 to 1	Counter Engine-Wise	GG-80-1	GG-69-1	BG-231-7	BH-119-6
	WW-77A-21	2.00 to 1	Engine-Wise	GG-81	GG-71	GJ-8	BG-231-7	BH-119-6
	WW-77A-22	2.67 to 1	Engine-Wise	GG-82	GG-71	GJ-9	BG-231-7	BH-119-6
WW-77A-23	3.79 to 1	Engine-Wise	Engine-Wise	GG-83	GG-73	GJ-10	BG-231-7	BH-119-6

See following page for weights and description.

**WW-77-A ETC. REDUCTION GEAR ASSEMBLIES
FOR TE AND TF ENGINES**

WEIGHTS OF PARTS SHOWN ON PRECEDING PAGE

Part Number	Net Wt.		Part Number	Net Wt.		Part Number	Net Wt.	
	Lb	Oz		Lb	Oz		Lb	Oz
BG-231-4	19		GG-81 (20 teeth)	2		WW-77A-9	59	
BG-231-5	19		GG-82 (15 teeth)	1	1	WW-77A-10	58	
BG-231-6	19		GG-83 (14 teeth)		15	WW-77A-11	60	
BG-231-7	19		GJ-8 (27" long)	1	13	WW-77A-12	63	
BH-119	14		GJ-9 (26" long)	1	12	WW-77A-13	65	
BH-119-1	14		GJ-10 (30" long)	2		WW-77A-14	64	
BH-119-2	14		WW-77-A	63		WW-77A-15	59	
BH-119-6	14		WW-77A-1	65		WW-77A-16	58	
GG-66-3 (30 teeth)	2	12	WW-77A-2	64		WW-77A-17	60	
GG-67-1 (62 teeth)	8	11	WW-77A-3	59		WW-77A-18	63	
GG-69-1 (73 teeth)	10	15	WW-77A-4	58		WW-77A-19	65	
GG-71 (40 teeth)	5	4	WW-77A-5	60		WW-77A-20	64	
GG-73 (53 teeth)	7	10	WW-77A-6	63		WW-77A-21	59	
GG-77-1 (69 teeth)	10	4	WW-77A-7	65		WW-77A-22	58	
GG-79-1 (23 teeth)	2		WW-77A-8	64		WW-77A-23	60	
GG-80-1 (19 teeth)	1	4						

INTERCHANGEABLE PARTS OF WW-77-A ETC. REDUCTION GEAR ASSEMBLIES

NOTE: Engines equipped with a reduction gear assembly, require a special main bearing plate, crankshaft and crankcase as follows:

BG-224-B-52 MAIN BEARING PLATE ASSEMBLY (not illustrated) consisting of:
 1 BG-224-B Bearing Plate 1 ME-130-2 Bearing Cup 1 PH-364 Oil Seal

CA-62-3-51 CRANKSHAFT ASSEMBLY (not illustrated) consisting of:
 1 CA-62-3 Crankshaft 1 ME-71 Bearing 1 PL-53 Key
 1 GA-36A-1 Gear 1 ME-130 Bearing

THE PART NUMBER OF THE CRANKCASE IS STAMPED ON THE FACE OF THE CASE ABOVE THE BEARING PLATE AT THE TAKE-OFF END

Ref. No.	Part Number	Description	No.			Ref. No.	Part Number	Description	No.		
			Req	Lb	Oz				Req	Lb	Oz
705	BG-150	PLATE for retaining bearing (outer)	1	1		721	GD-545	GASKET for cover to housing	1		1
706	BG-151	PLATE for retaining bearing (inner)	1			722	GD-650-1	GASKET for housing to crankcase	1		1
707	HF-265	SPACER for take-off shaft	1			723	SD-79	OIL INSTRUCTION TAG	1		1
708	LO-44	BREATHER	1			724	WA-55	TAKE-OFF SHAFT	1	6	14
709	ME-76	BEARING ASSEMBLY (outer)	1					STANDARD HARDWARE			
710		Consisting of:									
711		ME-76-1 Cup, Timken No. 3525	1		10						
712	ME-77	BEARING ASSEMBLY (inner)	1		15	725	PD-12	NUT, 7/16"-20 thread, hexagon steel	4		1
713		Consisting of:						For housing to crankcase mounting studs.			
714		ME-77-1 Cup, Timken No. 02820	1			726	PE-4	LOCKWASHER, 5/16" Positive	4		1
715	PA-279	DOWEL PIN for cover to housing	2					For outer bearing retainer plate.			
716	PC-392	STUD for housing to crankcase	1			727	PE-5	LOCKWASHER, 3/8" Positive	6		1
717	PH-202	OIL SEAL for take-off shaft Kickhafer Mfg. Co. No. A-31-106.	1					For cover to housing mounting above oil level.			
718	PH-206	COLLAR for take-off shaft spacer	1		2	728	PE-6	LOCKWASHER, 7/16" Positive	4		1
719	QD-543-A	GASKET for bearing retainer plate—inner	1		1			For housing to crankcase mounting.			
720	QD-544	GASKET for bearing retainer plate—outer	6		1	730	PH-22	PLAIN WASHER, 3/8" I.D. x 1/16" thick steel	5		1
								For cover to housing mounting, below oil level.			


Order parts from nearest **SERVICE STATION** shown in directory following parts list.
IMPORTANT: Always give Model, Specification and Serial Numbers as shown on name plate.

INTERCHANGEABLE PARTS OF WW-77-A ETC. REDUCTION GEAR ASSEMBLIES FOR TE AND TF ENGINES

Ref. No.	Part Number	Description	No. Req	Net Wt.	
				Lb	Oz
731	PL-24	KEY, No. 29 Woodruff For driven gear mounting.	1		1
732	PL-88	KEY, 1/4" square x 2" long For driver gear mounting.	1		1
733	XC-17	SCREW, 5/16"-18 thread x 3/4" long, flat head..... For inner bearing retainer plate.	4		1
734	XD-15	SCREW, 5/16"-18 thread x 3/4" long, hexagon head..... For outer bearing retainer plate.	4		1
735	XD-27	SCREW, 3/8"-16 thread x 1" long, hex- agon head..... For cover to housing mounting.	11		1
737	XE-17	SET SCREW, 1/4"-20 thread x 3/8" long headless..... For driver gear mounting.	1		1
738	XE-44	SET SCREW, 5/16"-18 thread x 5/8" long, headless..... For driven gear mounting.	1		1
739	XK-2	PIPE PLUG, 1/4" square head For oil level.	3		1
740	XK-3	PIPE PLUG, 3/8" square head For oil level—when take-off shaft is in horizontal position.	2		2
741	XK-4	PIPE PLUG, 1/2" square head For oil drain.	1		2
742	XK-88	REDUCER BUSHING, 3/8" to 1/8" pipe.. For mounting breather.	1		1

Order parts from nearest **SERVICE STATION** shown in directory following parts list.
IMPORTANT: Always give Model, Specification and Serial Numbers as shown on name plate.

WW-75-A ETC. CLUTCH REDUCTION GEAR ASSEMBLIES FOR TE AND TF ENGINES







NOTE: THE PART NUMBER OF THE COMPLETE ASSEMBLY IS STAMPED ON THE OIL INSTRUCTION TAG.

Parts are identified by reference number. See parts list for correct part number.

152520C

WP-404

**WW-75-A ETC. CLUTCH REDUCTION GEAR ASSEMBLIES
FOR TE AND TF ENGINES**

Position of Take-Off Shaft Viewing from Cranking End of Engine	Assembly Number	Reduction Ratio	Rotation of Take-off Shaft	Ref. No. 750 Driver Gear Part No.	Ref. No. 751 Driven Gear Part No.	Ref. No. 752 Chain Part No.	Ref. No. 753 Housing Part No.	Ref. No. 754 Cover Part No.
TAKE-OFF SHAFT BELOW 	WW-75A	2.07 to 1	Counter Engine-Wise	GG-116	GG-67-1	BG-227-4	BH-143
	WW-75A-1	3.00 to 1	Counter Engine-Wise	GG-117	GG-77-1	BG-227-4	BH-143
	WW-75A-2	3.84 to 1	Counter Engine-Wise	GG-118	GG-69-1	BG-227-4	BH-143
	WW-75A-3	2.00 to 1	Engine-Wise	GG-113	GG-71	GJ-8	BG-227-4	BH-143
	WW-75A-4	2.67 to 1	Engine-Wise	GG-114	GG-71	GJ-9	BG-227-4	BH-143
WW-75A-5	3.79 to 1	Engine-Wise	Engine-Wise	GG-115	GG-73	GJ-10	BG-227-4	BH-143
TAKE-OFF SHAFT ON LEFT HAND SIDE as Viewed from the Cranking End 	WW-75A-6	2.07 to 1	Counter Engine-Wise	GG-116	GG-67-1	BG-227-5	BH-143
	WW-75A-7	3.00 to 1	Counter Engine-Wise	GG-117	GG-77-1	BG-227-5	BH-143
	WW-75A-8	3.84 to 1	Counter Engine-Wise	GG-118	GG-69-1	BG-227-5	BH-143
	WW-75A-9	2.00 to 1	Engine-Wise	GG-113	GG-71	GJ-8	BG-227-5	BH-143
	WW-75A-10	2.67 to 1	Engine-Wise	GG-114	GG-71	GJ-9	BG-227-5	BH-143
WW-75A-11	3.79 to 1	Engine-Wise	Engine-Wise	GG-115	GG-73	GJ-10	BG-227-5	BH-143
TAKE-OFF SHAFT ON RIGHT HAND SIDE as Viewed from the Cranking End 	WW-75A-12	2.07 to 1	Counter Engine-Wise	GG-116	GG-67-1	BG-227-6	BH-143
	WW-75A-13	3.00 to 1	Counter Engine-Wise	GG-117	GG-77-1	BG-227-6	BH-143
	WW-75A-14	3.84 to 1	Counter Engine-Wise	GG-118	GG-69-1	BG-227-6	BH-143
	WW-75A-15	2.00 to 1	Engine-Wise	GG-113	GG-71	GJ-8	BG-227-6	BH-143
	WW-75A-16	2.67 to 1	Engine-Wise	GG-114	GG-71	GJ-9	BG-227-6	BH-143
WW-75A-17	3.79 to 1	Engine-Wise	Engine-Wise	GG-115	GG-73	GJ-10	BG-227-6	BH-143
TAKE-OFF SHAFT ON TOP 	WW-75A-18	2.07 to 1	Counter Engine-Wise	GG-116	GG-67-1	BG-227-7	BH-143-1
	WW-75A-19	3.00 to 1	Counter Engine-Wise	GG-117	GG-77-1	BG-227-7	BH-143-1
	WW-75A-20	3.84 to 1	Counter Engine-Wise	GG-118	GG-69-1	BG-227-7	BH-143-1
	WW-75A-21	2.00 to 1	Engine-Wise	GG-113	GG-71	GJ-8	BG-227-7	BH-143-1
	WW-75A-22	2.67 to 1	Engine-Wise	GG-114	GG-71	GJ-9	BG-227-7	BH-143-1
WW-75A-23	3.79 to 1	Engine-Wise	Engine-Wise	GG-115	GG-73	GJ-10	BG-227-7	BH-143-1

See following page for weights and description.

**WW-75-A ETC. CLUTCH REDUCTION GEAR ASSEMBLIES
FOR TE AND TF ENGINES**

WEIGHTS OF PARTS SHOWN ON PRECEDING PAGE

Part Number	Net Wt.		Part Number	Net Wt.		Part Number	Net Wt.	
	Lb	Oz		Lb	Oz		Lb	Oz
BG-227-4	19	8	GG-117 (23 teeth)	2	1	WW-75A-10	85	
BG-227-5	19	8	GG-118 (19 teeth)	1	12	WW-75A-11	87	
BG-227-6	19	8	GJ-8 (27" long)	1	13	WW-75A-12	89	
BG-227-7	19	8	GJ-9 (26" long)	1	12	WW-75A-13	89	8
BH-143	20		GJ-10 (30" long)	2		WW-75A-14	89	
BH-143-1	20		WW-75-A	89		WW-75A-15	86	
GG-67-1 (62 teeth)	8	11	WW-75A-1	89	8	WW-75A-16	85	
GG-69-1 (73 teeth)	10	15	WW-75A-2	89		WW-75A-17	87	
GG-71 (40 teeth)	5	4	WW-75A-3	86		WW-75A-18	89	
GG-73 (53 teeth)	7	10	WW-75A-4	85		WW-75A-19	89	8
GG-77-1 (69 teeth)	10	4	WW-75A-5	87		WW-75A-20	89	
GG-113 (20 teeth)	1	14	WW-75A-6	89		WW-75A-21	86	
GG-114 (15 teeth)	14		WW-75A-7	89	8	WW-75A-22	85	
GG-115 (14 teeth)	11		WW-75A-8	89		WW-75A-23	87	
GG-116 (30 teeth)	2	10	WW-75A-9	86				

INTERCHANGEABLE PARTS OF WW-75-A ETC. CLUTCH REDUCTION GEAR ASSEMBLIES

NOTE: Engines equipped with a clutch reduction gear assembly, require a special main bearing plate, crankshaft and crankcase as follows:

- BG-224B-S2 MAIN BEARING PLATE ASSEMBLY** (not illustrated) consisting of:
 1 BG-224-B Bearing Plate 1 ME-130-2 Bearing Cup 1 PH-364 Oil Seal
- CA-62-2-S1 CRANKSHAFT ASSEMBLY** (not illustrated) consisting of:
 1 CA-62-2 Crankshaft 1 ME-71 Bearing 1 PL-53 Key
 1 GA-36-A-1 Gear 1 ME-130 Bearing

THE PART NUMBER OF THE CRANKCASE IS STAMPED ON THE FACE OF THE CASE ABOVE THE BEARING PLATE AT THE TAKE-OFF END

Ref. No.	Part Number	Description	No.		Net Wt.		Ref. No.	Part Number	Description	No.		Net Wt.	
			Req		Lb	Oz				Req		Lb	Oz
760	BG-150	PLATE for retaining bearing (outer)	1		1		785	QD-650-1	GASKET for housing to crankcase	1		1	
761	BG-151	PLATE for retaining bearing (inner)	1		6		786	SD-79	OIL INSTRUCTION TAG	1		1	
762	BG-216	PLATE for clutch bearing	1		8		787	SD-125	INSTRUCTION PLATE For clutch adjustment.	1		1	
763	BH-127	COVER for inspection opening	1		12		788	VB-55-1	SHIFTER LEVER	1		2	
764	HF-265-A	SPACER for take-off shaft	1		6		789	VB-64-A	SHIFTER YOKE	1		1	8
765	HF-372-A	SPACER for ball bearing	1		3		790	WA-55-H	TAKE-OFF SHAFT	1		6	10
766	HF-392	SPACER for shifter yoke (Used only when take-off shaft is on the right or left hand side.)	4		2		791	WA-61-D	SHIFTER SHAFT	1		1	12
767	LO-44	BREATHER	1		1		792	WA-93	CLUTCH SHAFT	1		2	
768	ME-76	BEARING ASSEMBLY (outer) Consisting of: ME-76-1 Cup, Timken No. 3525	1		1	11	793	WC-280-A	CLUTCH ASSEMBLY Rockford Drilling Model 4½ L.O.C. No. CLA-1721-1.	1		12	
769		ME-76-2 Cone, Timken No. 3578	1		1	1			NOTE: See Rockford illustration and parts list for clutch parts.				
770			1		1	1	794	XD-14-2	SET SCREW for clutch drive hub	1		1	
771	ME-77	BEARING ASSEMBLY (inner) Consisting of: ME-77-1 Cup, Timken No. 02820	1		15				STANDARD HARDWARE				
772		ME-77-2 Cone, Timken No. 02877	1		6		795	PD-12	NUT, 7/16"-20 thread, hexagon steel For housing to crankcase mounting studs.	4		1	
773			1		9		796	PE-4	LOCKWASHER, 5/16" Positive For outer bearing retainer plate.	4		1	
774	ME-119	BALL BEARING for clutch shaft New Departure No. 3206.	1		8		797	PE-6	LOCKWASHER, 7/16" Positive For housing to crankcase mounting.	4		1	
775	ME-131-A	BALL BEARING for clutch shaft pilot New Departure No. 77503.	1		6		798	PE-46	LOCKWASHER, 5/16" External Everlock For clutch drive hub set screw.	1		1	
776	PA-279	DOWEL PIN for cover to housing	2		1		799	PH-22	PLAIN WASHER, 3/8" I.D. x 1/16" thick, steel For cover to housing mounting.	11		1	
777	PC-392	STUD for housing to crankcase	4		1		800	PH-30	PLAIN WASHER, 1/4" I.D. x 1/16" thick, copper 6-for inspection hole cover plate. 3-for bearing retainer plate.	9		1	
778	PH-202	OIL SEAL for take-off shaft Kickhaefer Mfg. Co. No. A-31-106.	1		4								
779	PH-234-A	OIL SEAL for shifter shaft	1		3								
780	PK-82	RETAINING RING for clutch shaft bearing	2		1								
781	QD-543-A	GASKET for bearing retainer plate—inner	1		1								
782	QD-544	GASKET for bearing retainer plate—outer	6		1								
783	QD-592	GASKET for inspection hole cover	1		1								
784	QD-619	GASKET for cover to housing	1		1								


Order parts from nearest **SERVICE STATION** shown in directory following parts list.
IMPORTANT: Always give Model, Specification and Serial Numbers as shown on name plate.

**INTERCHANGEABLE PARTS OF WW-75-A ETC. CLUTCH REDUCTION GEAR ASSEMBLIES
FOR TE AND TF ENGINES**

Ref. No.	Part Number	Description	No. Req.	Net Wt.		Ref. No.	Part Number	Description	No. Req.	Net Wt.	
				Lb	Oz					Lb	Oz
801	PL-17	KEY, No. 13 Woodruff For drive gear.	1		1	809	XD-27	SCREW, 3/8"-16 thread x 1" long, hexagon head For cover to housing mounting.	11		1
802	PL-24	KEY, No. 29 Woodruff For driven gear.	1		1	810	XD-30	SCREW, 3/8"-16 thread x 1-1/2" long, hexagon head..... For shifter lever clamp.	1		2
803	PL-47	KEY, No. 18 Woodruff For clutch drive hub.	1		1	811	XE-44	SET SCREW, 5/16"-18 thread x 5/8" long, headless For driven gear mounting.	1		1
804	SA-58	PLUG, 1-3/8" expansion..... For shifter shaft hole.	1		1	812	XH-26	TAPER PIN, No. 4 x 1-3/8" long For shifter yoke.	2		1
805	XA-36	SCREW, 1/4"-20 thread x 3/4" long, round head..... For inspection hole cover.	6		1	813	XK-2	PIPE PLUG, 1/4" square head For oil level.	3		1
806	XC-17	SCREW, 5/16"-18 thread x 3/4" long, flat head For inner bearing retainer plate.	4		1	814	XK-4	PIPE PLUG, 1/2" square head For oil filler.	1		2
807	XD-7	SCREW, 1/4"-20 thread x 1" long, hexagon head For clutch bearing retainer plate.	3		1	815	XK-6	PIPE PLUG, 1/2" Countersunk head For oil drain.	3		2
808	XD-15	SCREW, 5/16"-18 thread x 3/4" long, hexagon head For outer bearing retainer plate.	4		1	816	XK-77	STREET ELL, 1/8" pipe x 45° For breather mounting.	1		1

Order parts from nearest **SERVICE STATION** shown in directory following parts list.
IMPORTANT: Always give Model, Specification and Serial Numbers as shown on name plate.

ROCKFORD No. CLA-1721-1 CLUTCH ASSEMBLY
WISCONSIN MOTOR PART No. WC-280-A




206584C-A

Ref. No.	Rockford Part Number	Description	No Req	Ref. No.	Rockford Part Number	Description	No Req
1	CL-7248	CLUTCH HOUSING	1	17	CL-5092	COTTER PIN for link pins, 1/16" x 3/8" long.	6
2	CL-7012	ADJUSTMENT LOCK	1	18	UCL-5229-L	RELEASE SLEEVE ASSEMBLY	1
3	CL-3917-1	SCREW for adjustment lock, 1/4"-20 thread x 3/8" long, fillister head	1	19		Consisting of:	
4	CL-3468	WASHER for adjustment lock, 1/4" Shakeproof	1	20		CL-5229 Release sleeve	1
5	UCL-5230	DRIVE MEMBER ASSEMBLY	1			UCL-7-4966 Release bearing assembly	1
		Consisting of:		21	*	Consisting of:	
6		Splined center and plate assembly	1			Release bearing (2 halves)	
7		CL-4096-1 Facing (Raybestos No. 500B)	2	22		CL-3335-1 Hexagon head screw, 5/16"-24 thread x 1-3/4" long	2
		CL-1011 Brass rivet	6			CL-7356 Elastic stop nut, 5/16"-24 thread	2
8	UCL-1-5228-A	PRESSURE PLATE and LEVER ASSEMBLY ..	1	23	CL-4964	ADJUSTING RING	1
		Consisting of:		24	CL-5087	SPRING	3
9		UCL-5228 Pressure plate assembly	1	25	CL-5318	CLAMP SCREW, 3/8"-24 thread x 2-1/2" long, hexagon head	2
10		CL-5543 Lever	6	26	CL-5319	NUT, 3/8"-24 thread, light hexagon	2
11		CL-5156 Lever pin	3	27	CL-5211	SCREW LOCK	2
12		LM-408 Roller	3	28	PT-353	LOCKWASHER, 3/8" Positive	2
		CL-4775 Roller and CL-4971 Pin replaced by LM-408.					
13		CL-5092 Cotter pin, 1/16" x 3/8" long	3				
14	CL-4776	CONNECTING LINK	6				
15	CL-5153	LINK PIN (long)	3				
16	CL-5152	LINK PIN (short)	3				
						(*) Not serviced separately from sub-assembly it is included in.	

Order parts from nearest **SERVICE STATION** shown in directory following parts list.
IMPORTANT: Always give Model, Specification and Serial Numbers as shown on name plate.


FUEL STRAINER ASSEMBLIES




Ref. No.	Part Number	Description	Net Wt.	
			No. Req	Lb Oz
	LP-19	FUEL STRAINER ASSEMBLY (With Shut-off valve in cover, and glass bowl) Tillotson No. OW-418-T.	1	8
	LP-19-A	FUEL STRAINER ASSEMBLY (With Shut-off valve in cover, and metal bowl) Tillotson No. OW-449-T.	1	7
	LP-19-B	FUEL STRAINER ASSEMBLY (Without Shut-off valve in cover, and glass bowl) Tillotson No. OW-444.	1	6
	LP-19-C	FUEL STRAINER ASSEMBLY (Without Shut-off valve in cover, and metal bowl) Tillotson No. OW-476-T.	1	5
The following serviceable parts are interchangeable for the above strainers.				
495	OW-352	FILTER SCREEN	1	1
496	OW-363	GLASS BOWL	1	2
	06137	METAL BOWL	1	1
497	OW-447	CLAMP WIRE and NUT ASSEMBLY	1	1
498	06096	BOWL GASKET (Wisconsin No. QD-653)	1	5

LP-43 FUEL STRAINER (SMALL)

NOTE: The LP-43 small fuel strainer is furnished by either the **TILLOTSON** or **CRIPPEN** Companies. The strainers are interchangeable as complete units, but only the glass bowl, gasket and screen are interchangeable as service replacement parts.



Ref. No.	Part Number	Description	Net Wt.	
			No. Req	Lb Oz
	OW-480-T	TILLOTSON FUEL STRAINER ASSEMBLY (Wisconsin No. LP-43)	1	6
600	07766	CLAMP WIRE and NUT ASSEMBLY	1	1
601	07769	NEEDLE VALVE ASSEMBLY	1	1
		Includes 0705 Packing.		
602	07770	COVER	1	2
	08322	REPAIR PARTS KIT	1	3
		Consisting of:		
601		07769 Needle Valve Assembly	1	1
604		07759 Glass Bowl	1	1
605		08227 Thiokol Gasket	1	1
606		07762 Screen	1	1
- OPTIONAL -				
	830	CRIPPEN FUEL STRAINER ASSEMBLY (Wisconsin No. LP-43)	1	6
610	100-A	BAIL ASSEMBLY	1	2
611	100-6-7-8-9	NEEDLE VALVE ASSEMBLY	1	1
		Includes 100-9 Packing.		
612	100-1	COVER	1	2
	100-19	REPAIR PARTS KIT	1	3
		Consisting of:		
611		100-6-7-8-9 Needle Valve Assembly	1	1
613		100-2 Glass Bowl	1	1
614		100-10N Neoprene Gasket	1	1
615		100-11 Screen	1	1



Order parts from nearest **SERVICE STATION** shown in directory following parts list.
IMPORTANT: Always give Model, Specification and Serial Numbers as shown on name plate.


INSTRUCTIONS AND PARTS LIST FOR FUEL PUMP

WISCONSIN MOTOR No.

LP-42-A
LP-42-B
LP-42-C
LP-42-F

BLACKSTONE No.

GI-205
GI-206
GI-207
GI-210



176824C

The fuel pump, like all other parts of the engine, is subject to wear and you will find that any time after 500 hours of use, its efficiency will gradually decrease. This is indicated by the engines faltering at high speeds or when heavy loads are suddenly applied. The pump can easily be restored to its normal efficiency by the installation of a Wisconsin Motor No. LQ-28 diaphragm kit (standard) or LQ-28-A diaphragm kit (Government - cold weather).

1. Remove the fuel lines and the two mounting bolts which hold the pump to the engine. Take the pump to a work bench or suitable place.
2. With file, make an indicating mark across a point at the union of castings (11 and 12). This is a positive location of the fuel line positions when reassembling. Remove four assembly screws (15) and remove fuel head.
3. Turn head (12) over and remove one screw (16). Remove (10, 3, 6 and 5) valve assemblies, noting their positions. Discard the above parts (3, 6 and 5).
4. Clean fuel head thoroughly with gasoline and a fine wire brush.
5. Holding fuel head, (12) with diaphragm surface (containing four clearance holes) up, reassemble the valve spring (3) and valve (6) into the cavity from which they were removed. Now place new gasket (5) in position and reassemble the valve retainer (10) into position and lock it by inserting and tightening the fuel pump valve retainer screw (16).
6. Place this fuel head assembly in a clean place and we are ready to rebuild the lower diaphragm section.
7. Using a screw driver, inserted into the coils of rocker arm spring (13), remove this spring and save.
8. Holding the mounting bracket (11) in the left hand with the rocker arm toward the body and the thumb nail on the end of the link (9) with the heel of the right hand on the diaphragm (2) compress the diaphragm spring (4) at the same time, turning in a clockwise position 90°. This will unhook the diaphragm from the link (9) so it can be removed.
9. Clean the mounting bracket (11) with gasoline and fine wire brush.
10. Replace the new diaphragm operating spring (4), standing it into casting (11). Repeat in reverse step eight, using the new diaphragm. Replace rocker arm spring removed in step seven.
11. Mount this assembly back on the engine in the position from which it was removed, using the new mounting gasket which is the last piece of the repair kit.
12. Crank the engine over to a position where the diaphragm (2) is laying flat on the mounting bracket (11). Place the fuel head (12) back in position so that the indicating marks of step one are in line, and start the four assembly screws approximately three turns. Again, crank the engine over to a position where the diaphragm (2) is pulled down into (11) mounting bracket and tighten the four assembly screws (15) tightly.
13. Connect the fuel lines and you have a completely rebuilt fuel pump.

FUEL PUMP PARTS LIST
(Blackstone Part Numbers Shown)

Ref. No.	Part Number MODELS TE, TF		Part Number MODELS AEN		Description	Qty.
	LP-42-A Pump Blackstone GI-205 (Standard)	LP-42-C Pump Blackstone GI-207 (Cold Weather)	LP-42-B Pump Blackstone GI-206 (Standard)	LP-42-F Pump Blackstone GI-210 (Cold Weather)		
1	FP-918	FP-918	FP-916	FP-916	ROCKER ARM	1
** 2	LQ-28	LQ-28-A	LQ-28	LQ-28-A	DIAPHRAGM KIT.....	1

THE FOLLOWING PARTS ARE INTERCHANGEABLE ON ALL THE ABOVE
FUEL PUMP ASSEMBLIES


Ref. No.	Blackstone Part Number	Description	Qty.
* 3	FP-900	VALVE SPRING	2
* 4	FP-901	DIAPHRAGM SPRING	1
* 5	FP-903	VALVE GASKET	1
* 6	FP-904	VALVE	2
7	FP-905	ROCKER ARM PIN	1
8	FP-906	SPRING CLIP for rocker arm	1
9	FP-910	LINKAGE	1
10	FP-911 and FP-907	VALVE PLATE and SEATS	1
		NOTE: FP-911 Plate and 2 FP-907 Seats must be ordered together.	
11	FP-912	MOUNTING BRACKET	1
12	FP-913	HEAD	1
13	FP-914	ROCKER ARM SPRING	1
* 14	FP-917	MOUNTING FLANGE GASKET (Not illustrated)	1
15	FP-920	ASSEMBLY SCREW and LOCKWASHER	4
16	FP-927	VALVE PLATE SCREW and LOCKWASHER	1
		No. 6-32 thread x 3/8" long, binder head screw.	
		No. 6 shakeproof external lockwasher.	

** Parts marked with an asterisk (*) are included in the LQ-28 (Standard) and LQ-28-A (Cold Weather) diaphragm kits.

WISCONSIN MOTOR CORPORATION
Milwaukee 46, Wisconsin

Order parts from nearest **SERVICE STATION** shown in directory following parts list.
IMPORTANT: Always give Model, Specification and Serial Numbers as shown on name plate.

**TT-66-F GOVERNOR IDLE CONTROL ASSEMBLY
FOR TE AND TF ENGINES**




REF. NO.	PART NUMBER	DESCRIPTION	NO. REQ.	NET WEIGHT	
				Lb	Oz
	TT-66-F	GOVERNOR CONTROL ASSEMBLY - Complete	1		
491	PI-171-A-S1	CONTROL ROD ASSEMBLY	1		5
		Consisting of:			
492		1 PI-171-A Control Rod			2
493		1 VE-452-A Control Knob			2
494		2 VE-657 Lock Nuts, short			1
495		1 VE-657-A Lock Nut, long			1
496	SA-68-A	VALVE TAPPET INSPECTION COVER	1		3
497	XD-21	SCREW, 5/16"-18 thread x 1 1/2" long, hexagon head	2		1
		For mounting inspection covers.			

Order parts from nearest **SERVICE STATION** shown in directory following parts list.
IMPORTANT: Always give Model, Specification and Serial Numbers as shown on name plate.


SK-1091-C, SK-1091-F and SK-1091-J FLYWHEEL ROTATING SCREENS FOR ENGINE MODELS TE, TF and TFD

Flywheel Rotating Screen, Illustration SK-1091-J, replaced SK-1091-C and -F, the screens themselves are not interchangeable. When ordering parts, in addition to the engine Serial and Specification Numbers, give the equipment manufacturers name.



Ref. No.	Part Number	Description	No. Req.	Net Wt.	
				Lb	Oz
875	NC-145G-8	FLYWHEEL, in place of standard flywheel (for manual starting).	1	34	
	NC-145G-9-S1	FLYWHEEL ASSEMBLY (for electric starting) Consisting of:		35	
		GH-46 Ring gear	1	1	
		NC-145G-9 Flywheel (not serviced separately)	1		
		XE-17 Set screws	3		1
876	SE-201D-S2	ROTATING SCREEN ASSEMBLY	1	2	
		Consisting of:			
877	PH-426	Grommet	1		1
	SE-201-D	Screen (not serviced separately)	1		
878	XA-104	Lok-Thread screws	3		1
879	UC-75-S1	STARTING CRANK NUT ASSEMBLY.... (Part of standard engine)	1	1	
		Consisting of:			
	PA-333	Pin			
	UC-75	Crank nut			

(OBSOLETE) FLYWHEEL ROTATING SCREEN



Ref. No.	Part Number	Description	No. Req.	Net Wt.	
				Lb	Oz
885	NC-145B-8	FLYWHEEL (for manual starting)	1		
		Replaced by NC-145G-8, but SE-201D-S3 Rotating Screen Kit must also be ordered.			
	NC-145B-9-S1	FLYWHEEL ASSEMBLY (for electric starting) replaced by NC-145G-9-S1, but SE-201D-S3 Rotating Screen Kit must also be ordered.	1		
		NOTE: The new style flywheel with the SE-201D-S3 Kit, makes the Rotating Screen set-up identical to the Rotating Screen as shown above in Illustration SK-1091-J.			
886	PC-475	STUD, replaced by PC-475D-S1 (Ref. No. 887) includes XA-104 Screw	3		
887	PC-475D-S1	STUD ASSEMBLY	3		3
		Consisting of:			
	PC-475D Stud	XA-104 Screw			
888	PD-198	LOCKNUT, 1/4"-20 thread	3		1
		For obsolete PC-475 stud.			
889	PH-84	WASHER for locknut, 1/4" I.D. x 1/2" O.D x 1/16" thick, plain steel	3		1
890	SE-201-C	ROTATING SCREEN	1	1	
891	UC-156-A	STARTING CRANK NUT ASSEMBLY....	1	1	4
		Consisting of:			
892	PA-333	Crank pin	1		1
893	PH-410	Washer	1		2
	LJ-370-1	Tube (not serviced separately)	1		
	UC-156	Nut (not serviced separately)	1		
894	XA-104	LOK-THREAD SCREW for mounting screen mounting	3		1

Order parts from nearest **SERVICE STATION** shown in directory following parts list.
IMPORTANT: Always give Model, Specification and Serial Numbers as shown on name plate.

INDEX

	PAGE	
Air Cleaner	8	Illustration of Engines
Backfires Through Carburetor	17	Knocks - Engine
Battery Ignition Distributor	11	Lubrication
Battery Ignition - Wiring and Timing Diagram ...	13	Lubrication System - Diagram
Carburetor Adjustment	10	Magneto Breaker Point Adjustment
Carburetor Repair - See Manufacturer's bulletin in back of Manual.		Magneto Ignition Spark
Choke	10	Magneto Repair - See Manufacturer's bulletin in back of Manual.
Clutch	24	Magneto Timing Diagram
Clutch Adjustment	24	Magneto Timing
Compression	16	Oil - Grade of
Compression - Restoring	15	Oil Pump - Engine Base and
Cooling	7	Oil Spray Nozzles
Crankshaft - End Play	22	Overheating
Cross Section of Engine	5	Parts List
Cylinders - Oversize (See Cylinder Block)	21	Piston - Rings - Rod Clearances
Disassembling and Reassembling	17	Reduction Gears
Distributor - Battery Ignition	11	Safety Precautions
Electric Starter and Generator	14	Service Station Directory, See back of Manual.
Engine Models	1	Spark Plugs
Firing Order	14	Starting and Operating Instructions
Fuel	9	Starting - Crank
Fuel Pump	9	Starting Difficulties
Gasoline Strainer	9	Stop Engine - Vapor Lock and Dieseling
Gears - Timing (Fig. 22)	20	Storage of Engine for Winter
General Information and Design	7	Surging or Galloping
Horse Power	7	Troubles - Causes and Remedies
Governor	7	Valves - Grinding and Tolerances
Ignition Switch	10	Valve Tappets
Ignition Troubles	16	Warm-Up Period, Overspeeding

ZENITH 161 SERIES CARBURETORS

FOR WISCONSIN MOTOR CORPORATION




Figure 1


The Zenith 61 and 161 Series carburetors are of updraft single venturi design. They are made in $\frac{5}{8}$ " and $\frac{7}{8}$ " S.A.E. barrel sizes; with $\frac{5}{8}$ ", $\frac{7}{8}$ ", 1" and $1\frac{1}{4}$ " S.A.E. flange sizes available. They are made with selective fuel inlet, with or without a back suction economizer and a main jet adjustment.

They are "balanced" and "sealed", and the semi-concentric fuel bowl allows operation to quite extreme angles without flooding or starving. This design makes them particularly adaptable to smaller farm tractors and a great variety of agricultural machines and industrial units.

FUEL SUPPLY SYSTEM

The fuel supply system is made up of the threaded fuel inlet, the fuel valve seat, fuel valve, float and fuel bowl.

The fuel supply line is connected to the threaded inlet. The fuel travels through the fuel valve seat and passes around the fuel valve and into the fuel bowl. The level of the fuel in the fuel chamber is regulated by the float through its control of the fuel valve. The fuel valve does not open and close alternately but assumes an opening, regulated by the float, sufficient to maintain



FUEL SUPPLY SYSTEM

Figure 2

a proper level in the fuel chamber equal to the demand of the engine according to its speed and load.

The inside bowl vent as illustrated by the passage originating in the air intake and continuing through to the fuel bowl, is a method of venting the fuel bowl to maintain proper air fuel mixtures even though the air cleaner may become restricted. This balancing is frequently referred to as an "inside bowl vent."

IDLE SYSTEM

The idle system consists of the idle discharge port, idle air passage, idle adjusting needle, idle jet, and fuel passage.

The fuel for idle is supplied through the main jet to a well directly below the main discharge jet. The pick-up passage is connected to this well by a restricted drilling at the bottom of this passage. The fuel travels through this channel to the idle jet calibration. The air for the idle mixture originates back of (or from behind) the main venturi. The position of the idle adjusting needle in this passage controls the suction on the idle jet and thereby the idle mixture. Turning the needle in closer to its seat results in a greater suction with a smaller amount of air and therefore a richer mixture. Turning the needle out away from its seat increases the amount of air and reduces the suction, and a leaner mixture is delivered. The fuel is atomized and mixed with




Figure 3

the air in the passage leading to the discharge port (or priming plug) and enters the air stream at this point.

HIGH SPEED SYSTEM

The high speed system controls the fuel mixture at part throttle speeds and at wide open throttle. This system consists of a **venturi**, controlling the maximum volume of air admitted into the engine; the **main jet**, which regulates the flow of fuel from the float chamber to the main discharge jet; the **well vent**, which maintains uniform mixture ratio under changing suction




Figure 4

and engine speeds; and a **main discharge jet**, which delivers the fuel into the air stream.

The main jet controls the fuel delivery during the part throttle range from about one-quarter to full throttle opening. To maintain a proper

mixture ratio a small amount of air is admitted through the well vent into the discharge jet through the air bleed holes in the discharge jet at a point below the level of fuel in the metering well.

The passage of fuel through the high speed system is not a complicated process. The fuel flows from the fuel chamber through the main jet and into the main discharge jet where it is mixed with air admitted by the well vent, and the air-fuel mixture is then discharged into the air stream of the carburetor.

CHOKE SYSTEM

The choke system consists of a valve mounted on a shaft located in the air entrance and operated externally by a lever mounted on the shaft. The choke valve is used to restrict the air entering the carburetor. This increases the suction on the jets when starting the engine. The choke valve is of a "semi-automatic" type, having a poppet valve incorporated in its design, which is controlled by a spring.





Figure 5

The poppet valve opens automatically when the engine starts and admits air to avoid **over-choking** or **flooding** of the engine. The mixture required for starting is considerably richer than that needed to develop power at normal temperatures. As the engine fires and speed and suction are increased, the mixture ratio must be rapidly reduced. This change is accomplished through adjustment of the choke valve and the automatic opening of the poppet valve to admit more air when the engine fires.

Parts List for Zenith Model 161-7 Carburetors



CARB. REF. NO.	ZENITH ASS'Y. NO.	WISCONSIN PART NO.
1	10034E	L48
2	S717	L48-1
3	S632B	L48-2
4	S732	L48-3
5	S1164	L48-B
6	S1329	L48-C
7	S1548	L48-D
8	10741	L48-E
9	10457	L48-F
10	10748	L48-G
11	10535	L48-H
12	10595	L48-J
13	10610	L48-K
14	10627	L48-L
15	10788	L48-M
16	10737	L48-N
17	10816	L48-P
18	10926	L48-Q
19	10858	L48-U
20	10907	L48-V
21	10932	L48-Y
22	10955	L48-Z
23	11003	L48-AA
24	11206	L48-AB
25	11372	L48-AC
26	11595	L48-AD
27	11494	L48-AE
28	11593	L48-AL
29	12095	L48-BF & -1

Ref No	Zenith Part Number	Description
1	C21-88	Plate—Throttle (for 1, 2, 3, 4, 5, 7, 8, 9, 10, 11, 13, 14, 15, 16, 17, 18, 20, 21, 22, 23)
1	C21-176	Plate—Throttle (for 6, 12, 19, 24, 25, 26, 27, 28, 29)
2		Body—Throttle (Not serviceable. Purchase complete carburetor.)
3	†CT48-9	Seal—Shaft Packing
4	†CT52-57	Retainer—Shaft Seal
5	CT48-8	Seal—Idle Needle (for 27)
6	CT52-1	Retainer—Needle Seal (for 27)
7	T315B5-3	Screw—Throttle Plate
9	T858-10	Screw—Throttle Stop (for all except 19, 24, 26, 27, 28)
9	T858-12	Screw—Throttle Stop (for 24, 26, 27, 28, 29)
9	T8B10-15	Screw—Throttle Stop (for 19)
	C111-19	Spring—Throttle Stop Screw (for 19)
14	C29-491	Shaft and Lever—Throttle (for 1, 2, 3, 4, 5, 6, 7, 8, 12, 14, 15, 17, 18, 24, 27, 29)
14	C29-858	Shaft and Lever—Throttle (for 9, 16, 21)
14	C29-875	Shaft and Lever—Throttle (for 11, 13)
14	C29-926	Shaft and Lever—Throttle (for 10, 22, 23, 25, 26, 28)
14	C29-172-1	Shaft and Lever—Throttle (for 19)
14	C29-963	Shaft and Lever—Throttle (for 20)
15	CT91-3	Plug—Fuel Inlet (1/8" Pipe)
16	C111-9	Spring—Adjusting Needle (for all except 6, 12, 19, 24, 27, 29)
16	C111-17	Spring—Adjusting Needle (for 6, 12, 24, 27)

Ref No	Zenith Part Number	Description
16	C111-63	Spring—Adjusting Needle (for 19)
17	†C46-25	Needle—Idle Adjusting (for all except 6, 12, 19, 24, 27)
17	C46-6	Needle—Idle Adjusting (for 6, 12, 24)
17	C46-32	Needle—Idle Adjusting (for 27)
17	C46-48	Needle—Idle Adjusting (for 19)
18	†C55-6-12	Jet—Idle (for all except 6, 12, 19, 24, 27, 29)
18	C55-22-13	Jet—Idle (for 6, 12, 19, 24, 27)
19	†T56-20	Washer—Fuel Valve Seat
20	†C81-17-35	Valve and Seat—Fuel (for 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 13, 16, 17, 20, 21, 22, 23, 29)
20	†C81-50-35	Valve and Seat—Fuel (for 12, 14, 15, 18, 19, 24, 25, 26, 27, 28)
21	C85-28	Float
22	†C120-4	Axle—Float
23	†C142-16	Gasket—Bowl to Body
24	C38-51-16	Venturi (for 7, 9, 10, 14, 16, 17, 18, 23, 25, 28)
24	C38-51-19	Venturi (for 1, 2, 3, 4, 5, 11, 20, 29)
24	C38-51-17	Venturi (for 21, 22, 26)
24	C38-51-18	Venturi (for 6, 8, 12, 13, 15, 19, 24, 27)
25	C66-47-40	Jet—Discharge (for 7, 8, 14, 15, 17, 18)
25	C66-47-45	Jet—Discharge (for 11)
25	C66-47-50	Jet—Discharge (for 3, 4, 5, 29)
25	C66-47-60	Jet—Discharge (for 1, 2, 20)
25	C66-47-6-40	Jet—Discharge (for 6, 12, 19, 24, 27)
25	C66-50-40	Jet—Discharge (for 9, 10, 16, 21, 22, 23, 25, 26, 28)

Ref No	Zenith Part Number	Description
25	C66-50-45	Jet-Discharge (for 13)
26	†T56-52	Washer-Discharge Jet
27	C77-18-13	Jet-Well Vent (for 2, 20)
27	C77-18-14	Jet-Well Vent (for 6, 12, 19, 24, 27)
27	C77-18-17	Jet-Well Vent (for 8, 9, 10, 11, 13, 15, 16, 21, 22, 23, 25, 26, 28)
27	C77-18-15	Jet-Well Vent (for 1, 7, 14, 17, 18)
27	C77-18-22	Jet-Well Vent (for 3, 4, 5, 29)
28	C109-2	Bracket-Choke (for 1, 2, 3, 4, 5, 6, 7, 8, 12, 14, 15, 17, 18, 20, 24, 27)
28	C109-2-1	Bracket-Choke (for 29)
28	C109-31	Bracket-Choke (for 9, 10, 11, 13, 16, 21)
28	C109-13	Bracket-Choke (for 19)
28	C109-63	Bracket-Choke (for 22, 23, 25, 26)
28	C109-46	Bracket-Choke (for 28)
29	T2158	Nut-Tube Clamp Screw (for 1, 2, 3, 4, 5, 6, 7, 8, 12, 14, 15, 17, 18, 20, 24, 28, 29)
29	T22B8	Nut-Tube Clamp Screw (for 19)
30	C110-1	Clamp-Bracket Tube (for 1, 2, 3, 4, 5, 6, 7, 8, 12, 14, 15, 17, 18, 19, 20, 24, 26, 27, 28, 29)
31	T158-10	Screw-Tube Clamp (for 1, 2, 3, 4, 5, 6, 7, 8, 12, 14, 15, 17, 18, 20, 24, 26, 27, 28)
31	T1B8-10	Screw-Tube Clamp (for 19)
31	T8S8-10	Screw-Tube Clamp (for 29)
32	T45-8	Lockwasher-Shaft Nut (for 1, 2, 3, 4, 5, 6, 7, 8, 12, 14, 15, 17, 18, 19, 20, 24, 27, 28, 29)
32	T41-10	Lockwasher-Shaft Nut (for 9, 10, 11, 13, 16, 21, 22, 23, 25, 26)
33	T2258	Nut-Choke Shaft (for 1, 2, 3, 4, 5, 6, 7, 8, 12, 14, 15, 17, 18, 20, 24, 27, 28, 29)
33	T22510	Nut-Choke Shaft (for 9, 10, 11, 13, 16, 21, 22, 23, 25, 26)
33	T22B8	Nut-Choke Shaft (for 19)
34	T8S8-8	Screw-Lever Swivel (for 1, 2, 3, 4, 5, 6, 7, 8, 10, 12, 14, 15, 17, 18, 20, 24, 26, 27, 29)
34	T158-6	Screw-Lever Swivel (for 28)
34	T1B8-6	Screw-Lever Swivel (for 19)
35	C106-104	Lever-Choke (for 1, 2, 3, 4, 5, 6, 7, 8, 12, 14, 15, 17, 18, 20, 24)
35	CR106-157	Lever-Choke (for 9, 10, 11, 13, 16, 21, 22, 23, 25, 26)
35	C106-57	Lever-Choke (for 19)
35	C106-127	Lever-Choke (for 28)
35	C106-186	Lever-Choke (for 27)
35	C106-2	Lever-Choke (for 29)
36	C140-2	Screw-Bracket (for all except 19, 28, 29)
36	C140-20	Screw-Bracket (for 19)
36	C140-7	Screw-Bracket (for 28)
37	C112-6	Spring-Lever Return (for 1, 2, 3, 4, 5, 6, 7, 8, 12, 14, 15, 17, 18, 19, 20, 24, 28, 29)
37	C112-11	Spring-Lever Return (for 9, 10, 11, 13, 16, 21, 22, 23, 25, 26)
37	C117-68	Spring Lever Return (for 27)
38	CT48-7	Seal-Choke Shaft (for 27)
39	CT52-13	Retainer-Choke Shaft (for 27)
40	C105-60	Shaft-Choke (for 1, 2, 3, 4, 5, 6, 7, 8, 12, 14, 15, 17, 18, 19, 20, 24, 28, 29)
40	C105-298	Shaft-Choke (for 27)

Ref No	Zenith Part Number	Description
40	C108-107	Shaft and Lever-Choke (for 9, 10, 11, 13, 16, 21, 22, 23, 25, 26)
42	T315B5-3	Screw-Choke Plate
43	C101-17	Plate-Choke (for 1, 2, 3, 4, 5, 7, 9, 10, 11, 13, 14, 16, 20, 21)
43	C101-60	Plate-Choke (for 6, 8, 12, 15, 17, 18, 22, 23, 25, 26, 28)
43	C102-110	Plate-Choke (for 24, 27, 29)
44	C138-24	Plug-Choke Shaft Hole (for 1, 2, 3, 4, 5, 6, 7, 8, 12, 14, 15, 17, 18, 19, 20, 24, 27, 28, 29)
45	†T56-23	Washer-Shaft Hole Plug (for 1, 2, 3, 4, 5, 6, 7, 8, 12, 14, 15, 17, 18, 19, 20, 24, 27, 28, 29)
46	CT52-7	Washer-Intake Drain
47	†CT57-12	Washer-Drain Felt
48	CT93S-51	Retainer-Felt Washer
49	B3-85A	Bowl-Fuel (for 1, 2, 3, 4, 5)
49	B3-85AB-1	Bowl-Fuel (for 29)
49	B3-85L	Bowl-Fuel (for 7, 8, 10, 14, 15, 17, 18)
49	B3-85L-1	Bowl-Fuel (for 6, 12, 19, 22, 23, 25, 26)
49	B3-85L-5	Bowl-Fuel (for 28)
49	B3-85R-1	Bowl-Fuel (for 9, 11, 13, 16, 21)
49	B3-85H-2	Bowl-Fuel (for 20)
49	B3-112-1	Bowl-Fuel (for 24)
49	B3-112B-2	Bowl-Fuel (for 27)
50	CT91-3	Plug-Bowl Drain (1/8" Pipe)
52	T301S10-10	Screw-Bowl to Body
53	†T56-24	Washer-Main Jet
54	C52-6-18	Jet-Main (for 7, 14, 16)
54	C52-6-19	Jet-Main (for 23)
54	C52-6-21	Jet-Main (for 6, 12, 19, 24, 27)
54	C52-6-23	Jet-Main (for 1, 13)
54	C52-6-24	Jet-Main (for 2, 20)
54	C52-6-25	Jet-Main (for 17, 18)
54	C52-6-26	Jet-Main (for 3, 8, 15, 29)
54	C52-6-28	Jet-Main (for 4, 5)
54	C52-6-30	Jet-Main (for 9, 10, 21, 22, 25, 26, 28)
54	C52-6-33	Jet-Main (for 11)
55	†T56-23	Washer-Passage Plug (or adjustment)
56	C71-21	Adjustment-Main Jet (for 2, 4, 5, 8, 9, 10, 11, 13, 15, 17, 18, 20, 21, 22, 25, 26, 28)
57	C138-23	Plug-Main Jet Passage (for 1, 3, 6, 7, 12, 14, 16, 23, 24, 27)
57	C138-52	Plug-Main Jet Passage (for 19)
57	C138-24	Plug-Main Jet Passage (for 29)
58	†C141-45	Gasket-Flange (not in C181-66 gasket set)
	C24-54Px2	Lever and Swivel-Throttle Clamp (for 19)
	C63-168	Tube-Idle Channel Filler (for 26, 27, 28)
	C181-66	Gasket Set
	LQ-36	Repair Kit (for 12, 14, 15, 18, 19, 24, 25, 26, 27, 28)
	LQ-38	Repair Kit (for 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 13, 16, 17, 20, 21, 22, 23, 29)

†Note: Items Included in Repair Kit.

ZENITH CARBURETOR DIVISION

696 HART AVENUE



DETROIT 14, MICHIGAN

Manufacturers of Zenith Carburetors and Filters

WICO MODEL XH-2D MAGNETO

WICO No. XH-1961C (Replaces XH-1961), WIS. No. Y-67, For MODELS TE and TF ENGINE
 WICO No. XH-2531C (Replaces XH-2531 and XH-1961C), WIS. No. Y-67-A, For MODELS TE, TF, TH ENGINE

INSTRUCTIONS

TIMING

The magneto is properly timed to the engine at the factory. If it becomes necessary to retune the magneto to the engine, refer to the diagram and instructions in the engine instruction book.

LUBRICATION

The only lubricating point in the magneto is the cam wiper felt (Ref. No. 17). This felt, which lubricates the breaker arm at point of contact with the cam, should be replaced whenever it is necessary to replace the breaker contacts.

IMPORTANT

Incorrectly adjusted spark plug gaps cause magneto failure more frequently than any other condition.

Spark plugs should be inspected at frequent intervals, the size of the gap should be carefully checked and adjusted and the plugs thoroughly cleaned.

All oil, grease, and dirt should frequently be wiped off the magneto, lead wires, and spark plug insulators. Keeping these parts clean and the spark plugs properly adjusted will improve the engine performance and at the same time will prolong the life of the magneto.

MAGNETO COVER

The magneto cover (Ref. No. 53) can be removed by loosening the four screws (Ref. No. 33) which hold it in place. When replacing the cover be sure that the cover gasket (Ref. No. 32) is in its proper place.

BREAKER CONTACTS - REPLACEMENT AND ADJUSTMENT

The breaker contacts should be adjusted to .015" when fully opened. To adjust the contacts, loosen the two clamp screws (Ref. No. 37) enough so that the contact plate can be moved.

Insert the end of a small screw driver in the adjusting

slot and open or close the contacts by moving the plate until the opening is .015", measuring with a feeler gauge of that thickness, tighten the two clamp screws.

To replace the contacts, remove the breaker spring clamp screw (Ref. No. 40), the breaker arm lock (Ref. No. 16) and washer (Ref. No. 12). Then lift the breaker arm from its pivot. Remove the aligning washer, 5717, and the two fixed contact clamp screws (Ref. No. 37). The breaker plate can then be removed.

If the contacts need replacing it is recommended that both the fixed contact and the breaker arm be replaced at the same time, using replacement breaker set X5996 (Ref. No. 39).

After assembly, the contacts should be adjusted as described above. The contacts should be kept clean at all times. Lacquer thinner is an ideal cleaner for this purpose. Use WICO tool S-5449, to adjust the alignment of the contacts so that both surfaces meet squarely.

CONDENSER

To remove the condenser (Ref. No. 31), first disconnect the condenser lead by removing the breaker arm spring screw (Ref. No. 40), then remove the two condenser clamp screws (Ref. No. 19) and the condenser clamp (Ref. No. 28). When replacing the condenser make sure it is properly placed and that the clamp screws are securely tightened.


COIL AND COIL CORE

The coil and coil core must be removed from the magneto housing as a unit. Disconnect the primary wire from the breaker arm spring terminal by removing screw (Ref. No. 40), take out the two coil core clamp screws (Ref. No. 20) and remove the clamps (Ref. No. 35). The coil and core can then be pulled from the housing. When replacing this group make sure that the bare primary wire is connected under the core clamp screw and that the insulated wire is connected to the breaker arm spring terminal.

WICO ELECTRIC COMPANY WEST SPRINGFIELD, MASSACHUSETTS, U.S.A.

WICO MODEL XH-2D MAGNETO

WICO SPEC. No. XH-1961C (Replaces XH-1961), WISCONSIN MOTOR No. Y-67
 WICO SPEC. No. XH-2531C (Replaces XH-2531 and XH-1961C), WISCONSIN MOTOR No. Y-67-A



The service parts for Spec. Nos. XH-2531, XH-2531C, XH-1961C and XH-1961 are interchangeable except where noted.

Ref. No.	Wico Part No.	Description	No Req	Ref. No.	Wico Part No.	Description	No Req
1	11874	INSULATING WASHER for ground stud	2	35	5633	COIL CORE CLAMP	2
2	11874	INSULATING WASHER for ground stud	1	*	5717	ALIGNING WASHER for breaker point	1
3	X-42XA	SPACING WASHER for driven flange	1	*	X5750	GROUND CONNECTION UNIT (includes Ref. Nos. 1; 2, 4, 7, 13, 14, 15 & 36)	1
4	M-55XA	LOCKWASHER for ground stud	2	36	X5757	GROUND LEAD GROUP	1
5	A-179X	TRIP ARM	1	37	5900	CLAMP SCREW for fixed contact (Sems)	2
6	15-186	DRIVE SPRING	1	38	5926	BALL BEARING SHIELD	1
7	IXA-256	WASHER for ground stud (steel)	1	39	X5996	BREAKER CONTACT SET	1
8	IVA-583	SPACING WASHER for drive cup	1	40	5431	CLAMP SCREW for breaker spring	1
9	2061A	DRIVE CUP	1	41	X7262	MAIN HOUSING REPLACEMENT ASSEMBLY, (XH-2531C)	1
10	2122	DRIVEN FLANGE SPACER	1		X8553	MAIN HOUSING REPLACEMENT ASSEMBLY, (XH-1961, & C, and XH-2531)	1
11	2288	DRIVE SPRING RETAINER	1	42	6199	OIL SEAL	1
12	3215	PIVOT WASHER for breaker arm	1	43	6204	OIL SLINGER	1
13	3230	NUT for ground stud	2	44	6424	IMPULSE LOCK RING	1
14	9820	INSULATING LOCK for ground stud	2	45	6425	THRUST WASHER	1
15	3945	GROUND STUD	1	*	6412	IMPULSE LOCK NUT	1
16	4210	BREAKER ARM LOCK	1	46	6465	CLAMP SCREW for impulse stop (Sems)	4
*	4589	NUT for impulse set screw (XH-1961 & C, XH-2531)	1	47	7644	BREAKER ARM FELT	1
17	5077	CAM WIPER FELT	1	48	6585	TRIP ARM SPRING	1
18	5250	NAME PLATE SCREW	2	49	X6586	DRIVEN FLANGE GROUP	1
19	5411	CLAMP SCREW for condenser (Sems)	2	50	X12810	COIL GROUP	1
20	5411	CLAMP SCREW for coil core (Sems)	2	51	6882	COIL CONTACT SPRING	1
21	5516	RETAINING RING for rotor bearing	1	52	Y7569	ROTOR (XH-1961C, XH-2531 & C)	1
22	5517	ROTOR BEARING	1	†	Y7054	ROTOR (XH-1961)	1
23	5518	IMPULSE SPACER	1	53	X7123	COVER UNIT (Includes Ref. # 32, 33, 51)	1
24	5519	GASKET for impulse stop	1	*	X7412	IMPULSE COUPLING UNIT (Includes Ref. Nos. 3, 5, 6, 8, 9, 10, 11, 44, 45, 48 & 49)	1
25	5520	SPACER for bearing cage group	1	*	8511	IMPULSE SET SCREW (XH-1961 & C, XH-2531)	1
26	X5521	BEARING CAGE GROUP (Incl. Ref. # 21, 22, 29) ..	1	54	X8555	IMPULSE STOP GROUP (XH-1961 & C, XH-2531) ..	1
28	6924	CONDENSER CLAMP (XH-1961C and XH-2531 & C) ..	1		X5549	IMPULSE STOP GROUP (XH-2531C)	1
	5532	CONDENSER CLAMP (XH-1961)	1	55	8792	NAME PLATE	1
29	5567	BEARING CAGE	1	*	10407	ALIGNING WASHER for breaker point (thin)	1
30	5610	BUSHING for breaker plate	1	56		DRIVE GEAR (Wis. Motor No. GD-93C-1) for TE, TF ..	1
31	X6916	CONDENSER ASSEMBLY (XH-1961C & XH-2531 & C) ..	1			DRIVE GEAR (Wis. Motor No. GD-93C-3) for TH	1
	X5614	CONDENSER ASSEMBLY (XH-1961)	1				
32	5618	COVER GASKET	1				
33	5622	COVER SCREW	4				
34	X5632	STOP BUTTON GROUP	1				


† Y7569 Rotor can be used in place of Y7054, but new Condenser X6916 and Clamp 6924 must also be used.



FAIRBANKS, MORSE MAGNETO PARTS LIST

WISCONSIN MOTOR Y-80-Series TYPE FM-X1-2B7-1

Specific magnetos listed below



* Y-80-S2 Includes A GD-93C-3 Drive Gear For TH, THD Engines.

* Y-80-S1 Includes A GD-93C-1 Drive Gear For TE, TF Engines.

NOTE: Refer To Engine Parts List For Part Number of Repair Kits.


Ref. No.	*Y-80-S2, *Y-80-S1 FM-X1-2B7-1 Part Number	Description	No. Req.	Ref. No.	*Y-80-S2, *Y-80-S1 FM-X1-2B7-1 Part Number	Description	No. Req.
1	10S12D	End cap screw, 10-24 x 3/4	4	21	L2514C	Switch assembly	1
2	BY2430	End cap	1	22	8N1	Screw nut	3
3	H2498	End cap gasket	1	23	8LW5	Screw lockwasher	1
4	C1498G	Fulcrum pin snap ring	1	24	M2514	Insulated lever	1
5	A2437A	Point set, cw	1	25	C6018	Insulating washer	2
7	6S6Z	Terminal screw, 6-32 x 3/8	1	26	K2457A	Switch bushing	1
8	8S6U	Support screw, 8-32 x 3/8	1	27	J2499A	Wire assembly	1
9	B5969	Support screw washer	1	28	8S14N	Switch screw, 8-32 x 7/8	1
10	G2788	Cam wick, cw	1	29	B3967	Coil lead spring	2
12	8S4U	Condenser screw, 8-32 x 1/4	1	30	Q2477C	Coil	1
14	SXY2433	Condenser	1	31	3K1	Key	1
15	6S6U	Support screw, 6-32 x 3/8	1	32	FV2480	Rotor	1
16	D2458	Support screw washer, #6	1	33	B1498D	Shaft snap ring	1
17	8S6G	Support screw, 8-32 x 3/8	4	34	C5949	Drive end bearing	1
18	V4631	Bearing support	1	35	B1498B	Bearing snap ring	1
20	A5950A	Cam end bearing	1	36	A195	Name plate	1

Y-80 Series
TYPE FMX1-2B7-1

Ref. No.	*Y-80-S2, *Y-80-S1 FM-X1-2B7-1 Part Number	Description	No. Req.
37	6S4U	Vent screw, 6-32 x 1/4	2
38	B6030A	Vent cover	2
39	C6032B	Vent screen	2
40	S2568	Pawl stop pin	1
42	DY2425	Housing	1
44	31SS14A	Coil bridge setscrew, 5/16-24 x 7/8	2
45	A2492C	Seal inner washer	1
46	G3861	Shaft seal	1
47	A2492A	Seal outer washer	1
49	ZV2563C	Coupling, complete	1

Ref. No.	*Y-80-S2, *Y-80-S1 FM-X1-2B7-1 Part Number	Description	No. Req.
52	A1498J	Pawl lock spring	1
53	Q2566	Coupling pawl	1
55	T5963	Pawl spring	1
57	GY2563	Hub assembly	1
59	D2565	Coupling spring	1
60	AZ5957	Coupling shell	1
63	F2572	Coupling bushing	1
65	M2570	Coupling nut	1

FIELD SERVICE AND ADJUSTMENT



GENERAL DESCRIPTION

Type FM-X1-2B7-1 magneto is adapted to Models TE, TF TH and THD engines manufactured by Wisconsin Motor Corporation. The magneto is of a split-coil design in that there isn't any distributor, but instead two sparks are provided simultaneously every 360° of rotation. The magneto is flange mounted, clockwise in rotation, and has a lag angle of 20° provided by a special impulse coupling.

SERVICE PROCEDURE

Improper functioning of the magneto is often believed to be the cause of engine difficulty arising from other sources, such as a flooded carburetor, insufficient fuel or air, loose ignition connections, or a defective spark plug. A brief engine inspection will often locate the trouble before the magneto is reached, and prevent maladjustment of parts in good condition. The magneto should be opened only when it is certain that the ignition spark produced is unsatisfactory. This condition may be determined by an ignition spark test, as explained in engine INSTRUCTION MANUAL.

SERVICING BREAKER POINTS

Remove the magneto end cap and inspect the breaker points for evidence of pitting or pyramiding. A small tungsten file or fine stone should be used to resurface the points. Badly worn or pitted points should be replaced. If it is necessary to resurface or replace the breaker points, it will also be necessary to adjust them to their proper clearance which is 0.015 inch at full separation.

The adjustment of breaker points is made in the following manner: Lightly loosen the two contact support locking screws, identified in Fig. 1. Then, with the points at full separation, move the contact support until the proper breaker point clearance is obtained. This is accomplished by means of a screwdriver inserted in the slot at the bottom of the contact support and pivoted between the two small bosses on the bearing support. Lock assembly in place by tightening locking screws, and take a final measurement of breaker point gap after the locking screws are tightened.




Fig. 1 END VIEW OF MAGNETO.

SEALING MAGNETO

Before replacing end cap on the magneto frame, clean the contact surfaces between cap and frame. Then coat the end cap contact surface with Fairbanks-Morse FMCO2 Gasket Varnish, place a new cork gasket in the joint, mount the end cap on the frame, and tighten the four screws securely.

FURTHER FIELD SERVICE NOT RECOMMENDED

The cam felt wick, if dry or hard, should be replaced by a new factory-impregnated wick. Other than this, magneto does not require field lubrication and any attempt to oil or grease the bearings is inadvisable. The lubricants should be renewed only during a complete overhaul of the magneto by a Factory-Authorized Magneto Service Center. Coil and condenser replacements, while simple, are not recommended unless test equipment is available.

TIMING MAGNETO TO ENGINE

Ignition timing is accomplished by correctly mounting magneto to the crankcase. Refer to 'MAGNETO TIMING' in engine INSTRUCTION MANUAL for assembly procedure.

Engine Warranty

WISCONSIN MOTOR, hereinafter referred to as "Manufacturer", warrants each new engine sold by the Manufacturer to be free from defects in material and workmanship, under normal use and service, for a period of one (1) year after the date of delivery to the original retail purchaser, and Manufacturer will, at its option, replace or repair, at one of the Manufacturer's factories, or at a point designated by the Manufacturer, any part or parts which shall appear to the satisfaction of the Manufacturer upon inspection at such point, to have been defective in material or workmanship. This Warranty does not obligate the Manufacturer to bear any transportation charges in connection with the replacement or repair of defective parts.

This Warranty shall not apply to any engine which shall have been installed or operated in a manner not recommended by the Manufacturer; nor to any engine which shall have been repaired, altered, neglected or used in any way which, in the Manufacturer's opinion, adversely affects its performance; nor to any engine in which parts not manufactured by the Manufacturer, or supplied by the Manufacturer or by one of Manufacturer's Distributors or Service Centers, have been used; nor to any accessories installed on the engine where the accessory manufacturer has its own warranty; nor to normal maintenance services or replacement of normal service items.

Manufacturer reserves the right to modify, alter, and improve any engine or parts without incurring any obligation to replace any engine or parts previously sold with such modified, altered, or improved engine or part.

THIS WARRANTY, AND THE MANUFACTURER'S OBLIGATION THEREUNDER, IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS, IMPLIED, OR STATUTORY, INCLUDING ANY WARRANTIES OF MERCHANTABILITY OR OF FITNESS FOR A PARTICULAR PURPOSE, and all other obligations or liabilities, including special or consequential damages or contingent liabilities arising out of the failure of any engine or part to operate properly. No person is authorized to give any other warranty or to assume any additional obligation on the Manufacturer's behalf unless made in writing and signed by an officer of the Manufacturer.

WISCONSIN MOTOR
DIVISION OF *Continental Motors Corporation*
MILWAUKEE, WISCONSIN 53246

MS-83-5
FEB., 1969



3 to 60.5 H.P.

WISCONSIN MOTOR CORPORATION
MILWAUKEE, WISCONSIN 53246

PRINTED IN U.S.A.